

Submersible Pump in Discharge Tube

Amacan S

60 Hz

Amacan S 650 - 364

Amacan S 650 - 365

Amacan S 650 - 404

Amacan S 650 - 405

Amacan S 800 - 505

Installation/Operating Manual



Mat. No.:

Legal information/Copyright

Installation/Operating Manual Amacan S

Original operating manual

All rights reserved. The contents provided herein must neither be distributed, copied, reproduced, edited or processed for any other purpose, nor otherwise transmitted, published or made available to a third party without the manufacturer's express written consent.

Subject to technical modification without prior notice.

© KSB SE & Co. KGaA, Frankenthal 2023-07-18

Contents

1	General.....	7
1.1	Principles	7
1.2	Installation of partly completed machinery.....	7
1.3	Target group.....	7
1.4	Other applicable documents.....	7
1.5	Symbols	7
1.6	Key to safety symbols/markings.....	8
2	Safety	9
2.1	General.....	9
2.2	Intended use	9
2.3	Personnel qualification and personnel training.....	9
2.4	Consequences and risks caused by non-compliance with these operating instructions	10
2.5	Safety awareness	10
2.6	Safety information for the operator/user	10
2.7	Safety information for maintenance, inspection and installation	10
2.8	Unauthorized modes of operation.....	11
3	Transport/Storage/Disposal	12
3.1	Checking the condition upon delivery	12
3.2	Transport.....	12
3.2.1	Transporting the delivered pump set to the place of installation.....	12
3.2.2	Placing the pump set in a vertical or horizontal position	12
3.2.3	Transporting the pump set.....	14
3.3	Storage/preservation	15
3.4	Return to supplier.....	16
3.5	Disposal	17
4	Description of the Pump (Set).....	18
4.1	General description	18
4.2	Product information.....	18
4.2.1	Product information as per Regulation No 1907/2006 (REACH)	18
4.3	Designation.....	18
4.4	Name plate.....	19
4.5	Design details.....	20
4.6	Installation types	21
4.7	Configuration and function.....	22
4.8	Scope of supply.....	23
4.9	Dimensions and weights	23
5	Installation at Site	24
5.1	Safety regulations.....	24
5.2	Checks to be carried out prior to installation.....	24
5.2.1	Checking the structural requirements	24
5.2.2	Checking the operating data	24
5.2.3	Checking the lubricant of the mechanical seal	24
5.2.4	Checking the direction of rotation	25
5.3	Lowering the pump set into the discharge tube.....	27
5.3.1	Information for correct installation.....	28
5.3.2	Installing the pump set without support rope.....	28
5.3.3	Installing the pump set with a support rope.....	29
5.3.4	Installing the pump set with a support rope and support spacer.....	32
5.4	Electrical system.....	39
5.4.1	Information for planning the control system.....	39
5.4.2	Connection to power supply	43

6	Commissioning/Start-up/Shutdown	46
6.1	Commissioning/start-up	46
6.1.1	Prerequisites for commissioning/start-up	46
6.1.2	Start-up	47
6.2	Operating limits	47
6.2.1	Operation on the power supply mains	47
6.2.2	Frequency of starts	48
6.2.3	Operation on a frequency inverter	48
6.2.4	Fluid handled	48
6.3	Shutdown/storage/preservation	49
6.3.1	Shutdown	49
6.3.2	Measures to be taken for shutdown	50
6.4	Returning to service	50
7	Servicing/Maintenance	52
7.1	Safety regulations	52
7.2	Servicing/inspection	53
7.2.1	Inspection work	54
7.3	Removing the pump set	55
7.3.1	Removing the pump set	55
7.3.2	Drainage/cleaning	57
7.3.3	Checking the cable bundle	57
7.3.4	Checking the ground conductor	57
7.3.5	Checking the mechanical seal leakage	58
7.3.6	Visually inspecting for corrosion	59
7.4	Lubrication and lubricant change	59
7.4.1	Lubricating the mechanical seal	59
7.4.2	Lubricating the rolling element bearings	63
7.5	Dismantling the pump set	64
7.5.1	General information/Safety regulations	64
7.5.2	Preparing the pump set	66
7.5.3	Removing the bellmouth	66
7.5.4	Removing the impeller	67
7.5.5	Removing the mechanical seal	68
7.5.6	Dismantling the motor section	69
7.6	Reassembling the pump set	71
7.6.1	General information/Safety regulations	71
7.6.2	Installing the replacement cable gland	72
7.6.3	Fitting the motor housing cover	73
7.6.4	Installing the mechanical seal	74
7.6.5	Fitting the impeller	77
7.6.6	Fitting the bellmouth	78
7.6.7	Adjusting the clearance	79
7.6.8	Leak testing	80
7.7	Checking the connection of power supply and motor	81
7.8	Tightening torques	81
7.9	Spare parts stock	82
7.9.1	Ordering spare parts	82
7.9.2	Recommended spare parts stock for 2 years' operation to DIN 24296	83
8	Trouble-shooting	84
9	Related Documents	86
9.1	General assembly drawing of pump sets with UAG motors (DKA motor)	86
9.2	Cable bundle	88
9.3	Wiring diagrams	90
9.3.1	Wiring diagram	90
9.3.2	Wiring diagrams for the sensors	91
9.4	Dimensions	93
9.4.1	UAG motors (650-364 to 800-505) [inch]	93

9.4.2	UAG motors (650-364 to 800-505) [mm].....	95
9.5	General arrangement drawings	97
9.5.1	General arrangement drawings [inch].....	97
9.5.2	General arrangement drawings [mm]	117
10	EU Declaration of Conformity	138
11	Certificate of Decontamination.....	139
	Index	140

Glossary

Certificate of decontamination

If a product is to be returned to the manufacturer, the customer declares in a certificate of decontamination that the product has been properly drained to eliminate any environmental and health hazards arising from components in contact with the fluid handled.

Close-coupled design

Motor directly fitted to the pump via a flange or a drive lantern

Submersible pump in discharge tube

A submersible motor pump which is completely submerged and suspended in a discharge tube

1 General

1.1 Principles

This operating manual is valid for the type series and variants indicated on the front cover.

The manual describes the proper and safe use of this equipment in all phases of operation.

The name plate indicates the type series and size, the main operating data, the order number and the order item number. The order number and order item number clearly identify the pump set and serve as identification for all further business processes.

In the event of damage, immediately contact your nearest KSB service facility to maintain the right to claim under warranty.

1.2 Installation of partly completed machinery

To install partly completed machinery supplied by KSB refer to the sub-sections under Servicing/Maintenance.

1.3 Target group

This operating manual is aimed at the target group of trained and qualified specialist technical personnel. (⇒ Section 2.3, Page 9)

1.4 Other applicable documents

Table 1: Overview of other applicable documents

Document	Contents
Data sheet	Description of the technical data of the pump (set)
Hydraulic characteristic curve	Characteristic curves showing head, NPSH required, efficiency and power input
General assembly drawing ¹⁾	Sectional drawing of the pump set
Sub-supplier product literature ¹⁾	Operating manuals and other product literature describing accessories and integrated machinery components
Spare parts lists ¹⁾	Description of spare parts

For accessories and/or integrated machinery components observe the product literature of the corresponding manufacturer.

1.5 Symbols

Table 2: Symbols used in this manual

Symbol	Description
✓	Conditions which need to be fulfilled before proceeding with the step-by-step instructions
▷	Safety instructions
⇒	Result of an action
⇔	Cross-references
1. 2.	Step-by-step instructions
	Note Recommendations and important information on how to handle the product

¹ If included in agreed scope of supply

1.6 Key to safety symbols/markings

Table 3: Definition of safety symbols/markings

Symbol	Description
	DANGER This signal word indicates a high-risk hazard which, if not avoided, will result in death or serious injury.
	WARNING This signal word indicates a medium-risk hazard which, if not avoided, could result in death or serious injury.
	CAUTION This signal word indicates a hazard which, if not avoided, could result in damage to the machine and its functions.
	General hazard In conjunction with one of the signal words this symbol indicates a hazard which will or could result in death or serious injury.
	Electrical hazard In conjunction with one of the signal words this symbol indicates a hazard involving electrical voltage and identifies information about protection against electrical voltage.
	Machine damage In conjunction with the signal word CAUTION this symbol indicates a hazard for the machine and its functions.



2 Safety

All the information contained in this section refers to hazardous situations.

In addition to the present general safety information the action-related safety information given in the other sections must be observed.

2.1 General

- This operating manual contains general installation, operating and maintenance instructions that must be observed to ensure safe operation of the system and prevent personal injury and damage to property.
- Comply with all the safety instructions given in the individual sections of this operating manual.
- The operating manual must be read and understood by the responsible specialist personnel/operators prior to installation and commissioning.
- The contents of this operating manual must be available to the specialist personnel at the site at all times.
- Information and markings attached directly to the product must always be complied with and kept in a perfectly legible condition at all times. This applies to, for example:
 - Arrow indicating the direction of rotation
 - Markings for connections
 - Name plate
- The operator is responsible for ensuring compliance with all local regulations which are not taken into account.

2.2 Intended use

- The pump (set) must only be operated in the fields of application and within the use limits which are described in the other applicable documents.
- Only operate pumps/pump sets which are in perfect technical condition.
- Do not operate the pump (set) in partially assembled condition.
- Only use the pump to handle the fluids described in the data sheet or product literature of the pump model or variant.
- Never operate the pump without the fluid to be handled.
- Observe the limits for continuous duty specified in the data sheet or product literature ($Q_{\min}$ and $Q_{\max}$) (to prevent damage such as shaft fracture, bearing failure, mechanical seal damage, etc).
- Observe the minimum flow rate and maximum flow rate indicated in the data sheet or product literature (to prevent overheating, mechanical seal damage, cavitation damage, bearing damage).
- Always operate the pump (set) in the direction of rotation it is intended for.

2.3 Personnel qualification and personnel training

All personnel involved must be fully qualified to transport, install, operate, maintain and inspect the machinery this manual refers to.

The responsibilities, competence and supervision of all personnel involved in transport, installation, operation, maintenance and inspection must be clearly defined by the operator.

Deficits in knowledge must be rectified by sufficiently trained specialist personnel training and instructing the personnel who will carry out the respective tasks. If required, the operator can commission the manufacturer/supplier to train the personnel.

Training on the pump (set) must always be supervised by technical specialist personnel.

2.4 Consequences and risks caused by non-compliance with these operating instructions

- Non-compliance with these operating instructions will lead to forfeiture of warranty cover and of any and all rights to claims for damages.
- Non-compliance can, for example, have the following consequences:
 - Hazards to persons due to electrical, thermal, mechanical and chemical effects and explosions
 - Failure of important product functions
 - Failure of prescribed maintenance and servicing practices
 - Hazard to the environment due to leakage of hazardous substances

2.5 Safety awareness

In addition to the safety information contained in this operating manual and the intended use, the following safety regulations shall be complied with:

- Accident prevention, health regulations and safety regulations
- Explosion protection regulations
- Safety regulations for handling hazardous substances
- Applicable standards, directives and laws

2.6 Safety information for the operator/user

- Fit protective equipment (e.g. contact guards) supplied by the operator for hot, cold or moving parts, and check that the equipment functions properly.
- Do not remove any protective equipment (e.g. contact guards) during operation.
- Provide the personnel with protective equipment and make sure it is used.
- Contain leakages (e.g. at the shaft seal) of hazardous fluids handled (e.g. explosive, toxic, hot) so as to avoid any danger to persons and the environment. Adhere to all relevant laws.
- Eliminate all electrical hazards. (In this respect refer to the applicable national safety regulations and/or regulations issued by the local energy supply companies.)
- If stopping the pump does not increase potential risk, fit an emergency-stop control device in the immediate vicinity of the pump (set) during pump set installation.

2.7 Safety information for maintenance, inspection and installation

- Modifications or alterations of the pump (set) are only permitted with the manufacturer's prior consent.
- Use only original spare parts or parts/components authorized by the manufacturer. The use of other parts/components can invalidate any liability of the manufacturer for resulting damage.
- The operator ensures that maintenance, inspection and installation is performed by authorized, qualified specialist personnel who are thoroughly familiar with the manual.
- Only carry out work on the pump (set) during standstill of the pump.
- Only perform work on the pump set when it has been disconnected from the power supply (de-energized).
- The pump (set) must have cooled down to ambient temperature.
- Pump pressure must have been released and the pump must have been drained.

- When taking the pump set out of service always adhere to the procedure described in the manual. (⇒ Section 6.3, Page 49)
- Decontaminate pumps which handle fluids posing a health hazard.
- As soon as the work has been completed, re-install and re-activate any safety-relevant devices and protective devices. Before returning the product to service, observe all instructions on commissioning. (⇒ Section 6.1, Page 46)

2.8 Unauthorized modes of operation

Never operate the pump (set) outside the limits stated in the data sheet and in this operating manual.

The warranty relating to the operating reliability and safety of the pump (set) supplied is only valid if the equipment is used in accordance with its intended use.

3 Transport/Storage/Disposal

3.1 Checking the condition upon delivery

1. On transfer of goods, check each packaging unit for damage.
2. In the event of in-transit damage, assess the exact damage, document it and notify KSB or the distributor and the insurance company about the damage in writing immediately.

3.2 Transport

	! DANGER Improper transport Danger to life from falling parts! Damage to the pump set! ▷ Use the attachment point provided for attaching the lifting accessory. ▷ Never lift the pump set by the electric cables. ▷ Use the lifting chain/rope included in the scope of supply exclusively for lowering or lifting the pump set into/out of the pump sump. ▷ Securely attach the lifting chain/rope to the pump and crane. ▷ Use tested, marked and approved lifting accessories only. ▷ Observe the regional transport regulations. ▷ Observe the documentation of the lifting accessory manufacturer. ▷ The load-carrying capacity of the lifting accessory must be higher than the weight indicated on the name plate of the pump set to be lifted. Take into account any additional system components to be lifted. ▷ Maintain a safe distance during lifting operations (load may swing when being lifted).
---	---

3.2.1 Transporting the delivered pump set to the place of installation




Fig. 1: Transporting the delivered pump set to the place of installation

- The pump set is supplied in a horizontal position on a suitable transport support.
- Use suitable lifting equipment to transport the pump set in its original packaging to its place of installation.
 Observe the marked centers of gravity and/or attachment points on the transport boxes.
 For the weight refer to the name plate or data sheet.

3.2.2 Placing the pump set in a vertical or horizontal position

	! WARNING Pump set tilting Risk of squashing hands and feet! ▷ Suspend or support the pump set.
---	---

	! WARNING Placing the pump set on unsecured and uneven surfaces Personal injury and damage to property! ▷ Always place the pump set on a solid and level surface with the pump set in a vertical position and the motor on top. ▷ Only place the pump set on a surface of sufficient load-carrying capacity. ▷ Use appropriate means to secure the pump set against tilting or tipping over. ▷ Refer to the weights given in the data sheet / on the name plate.
	! WARNING Incorrect handling of the electric cable Personal injury and damage to property! ▷ Secure electric cables against falling down. ▷ Avoid electric cables being laid on surfaces without fastening. ▷ When moving the pump set keep at a safe distance to the electric cables.
	! WARNING Improper handling when placing the pump set in a vertical/horizontal position Personal injury and damage to property! ▷ Use one or two pieces of lifting equipment, depending on the pump (set) size. ▷ Use appropriate means to secure the pump set against tilting, tipping over or rolling off. ▷ Maintain a safe distance during lifting operations (load may swing when being lifted). ▷ Use additional supports for the transport holder to secure it against tilting.
	! WARNING Improper lifting/moving of heavy assemblies or components Personal injury and damage to property! ▷ Use suitable transport devices, lifting equipment and lifting tackle to move heavy assemblies or components.
	CAUTION Improper storage Damage to the electric cables! ▷ Support the electric cables at the cable entry to prevent permanent deformation. ▷ Only remove the protective caps from the electric cables at the time of installation.




Fig. 2: Placing the pump set in a vertical or horizontal position

✓ Suitable lifting equipment (e.g. crane) has been selected.

1. a) If using one piece of lifting equipment: Attach the crane hook to the bail of the pump set.
b) If using two pieces of lifting equipment: Attach the crane hook of one crane to the bail of the pump set **and** loop a rope around the pump set and attach it to the crane hook of the second crane.
2. Lift the pump set with the lifting equipment.
 - ⇒ Guiding the pump set over the edge of the bellmouth or pump casing is only permissible on a wooden base!
 - ⇒ Protect the power cable against kinking!
3. Place the pump set on a level, clean surface and protect it against tilting, tipping over or rolling off.

3.2.3 Transporting the pump set

	 WARNING
	Incorrect positioning/placing down Personal injury and damage to property! ▷ Position the pump set vertically with the motor on top. ▷ Use appropriate means to secure the pump set against tilting and tipping over. ▷ Refer to the weights given in the data sheet/on the name plate.

	! WARNING Improper handling when placing the pump set in a vertical/horizontal position Personal injury and damage to property! ▷ Use one or two pieces of lifting equipment, depending on the pump (set) size. ▷ Use appropriate means to secure the pump set against tilting, tipping over or rolling off. ▷ Maintain a safe distance during lifting operations (load may swing when being lifted). ▷ Use additional supports for the transport holder to secure it against tilting.
	! WARNING Incorrect handling of the electric cable Personal injury and damage to property! ▷ Secure electric cables against falling down. ▷ Avoid electric cables being laid on surfaces without fastening. ▷ When moving the pump set keep at a safe distance to the electric cables.
	! WARNING Improper lifting/moving of heavy assemblies or components Personal injury and damage to property! ▷ Use suitable transport devices, lifting equipment and lifting tackle to move heavy assemblies or components.




Fig. 3: Transporting the pump set

Use suitable lifting equipment to transport the pump set in the illustrated position.

3.3 Storage/preservation

If commissioning is to take place some time after delivery, we recommend that the following measures be taken:

Store the pump set as follows:

- In its original packaging: in a horizontal position
- Without packaging: in a vertical position with the motor on top

	! WARNING Pump set tilting Risk of squashing hands and feet! ▷ Suspend or support the pump set.
---	---

	CAUTION Improper storage Damage to the electric cables! ▷ Support the electric cables at the cable entry to prevent permanent deformation. ▷ Only remove the protective caps from the electric cables at the time of installation.
	CAUTION Damage during storage due to humidity, dirt or vermin Corrosion/contamination of pump (set)! ▷ For outdoor storage cover the pump (set) and accessories with waterproof material and protect against condensation.
	CAUTION Wet, contaminated or damaged openings and connections Leakage or damage to the pump! ▷ Clean and cover pump openings and connections as required prior to putting the pump into storage.

Table 4: Ambient conditions for storage

Ambient condition	Value
Relative humidity	5 % to 85 % (non-condensing)
Ambient temperature	-4 °F to 158 °F [-20 °C to +70 °C]

- Store the pump set under dry and vibration-free conditions, if possible in its original packaging.
1. Rotate the impeller by hand once every three months.
 2. Spray-coat the inside wall of the pump casing and, in particular, the impeller clearance areas with a preservative.

	NOTE Observe the manufacturer's instructions for application/removal of the preservative.
---	---

3.4 Return to supplier

1. Drain the pump as per operating instructions. (⇒ Section 7.3.2, Page 57)
2. Flush and clean the pump, particularly if it has been used for handling noxious, explosive, hot or other hazardous fluids.
3. If the pump has handled fluids whose residues could lead to corrosion damage in the presence of atmospheric humidity or could ignite upon contact with oxygen, the pump must also be neutralized, and anhydrous inert gas must be blown through the pump to ensure drying.
4. Always complete and enclose a certificate of decontamination when returning the pump.
Indicate any safety measures and decontamination measures taken.
(⇒ Section 11, Page 139)

**NOTE**

If required, a blank certificate of decontamination can be downloaded from the KSB web site at: www.ksb.com/certificate_of_decontamination

3.5 Disposal**WARNING**

Fluids handled, consumables and operating supplies which are hot or pose a health hazard

Hazard to persons and the environment!

- ▷ Collect and properly dispose of the flushing fluid and of any residues of the fluid handled.
- ▷ Wear safety clothing and a protective mask if required.
- ▷ Observe all legal regulations on the disposal of fluids posing a health hazard.

1. Dismantle the pump (set).
Collect greases and other lubricants during dismantling.
2. Separate and sort the pump materials, e.g. by:
 - Metals
 - Plastics
 - Electronic waste
 - Greases and other lubricants
3. Dispose of materials in accordance with local regulations or in another controlled manner.

4 Description of the Pump (Set)

4.1 General description

- Submersible pump in discharge tube

Pump for handling pure water, pre-screened river water and stormwater, waste water without long fibers or large solid particles, and activated sludge

4.2 Product information

4.2.1 Product information as per Regulation No 1907/2006 (REACH)

For information as per European chemicals regulation (EC) No. 1907/2006 (REACH) see <https://www.ksb.com/en-global/company/corporate-responsibility/reach>.

4.3 Designation

Example: Amacan S 650-365 / 80 4 UAG2

Table 5: Designation key

Code	Description
Amacan	Type series
S	Impeller type
S	Mixed flow impeller
650	Nominal diameter of the discharge tube [mm]
365	Nominal impeller diameter [mm]
80	Motor size
4	Number of motor poles
UA	Motor version
UA	Without explosion protection
G2	Material variant
G2	Gray cast iron, standard material variant
G3	Gray cast iron with Zn anodes and shaft made of stainless steel 1.4057

4.4 Name plate




Fig. 4: Name plate: pump set (example)

1	Designation	2	KSB order number
3	Flow rate	4	Maximum fluid temperature and ambient temperature
5	Enclosure	6	Motor type
7	Rated power	8	Rated speed
9	Rated voltage	10	Rated current
11	Head	12	Year of construction
13	Total weight	14	Maximum immersion depth ∇
15	Thermal class of winding insulation	16	Motor number
17	Power factor at rated operating point	18	Rated frequency
19	Service factor	20	Starting current

4.5 Design details

Design

- Fully floodable submersible pump in discharge tube (submersible motor pump)
- Not self-priming
- Close-coupled design
- Single-stage
- Vertical installation

Drive

- Three-phase asynchronous squirrel-cage motor

Shaft seal

- Two bi-directional mechanical seals in tandem arrangement, with liquid reservoir
- Leakage chamber

Impeller type

- Open mixed flow impeller







Bearings

- Grease-packed rolling element bearings

4.6 Installation types

Six different types are available for selection:²⁾

Table 6: Overview of installation types

		
BU discharge tube Overflow design for installation in open intake chamber	CU discharge tube Design with underfloor discharge for installation in open intake chamber	DU discharge tube Design with above floor discharge nozzle for installation in open intake chamber
		
BG discharge tube Overflow design for installation in covered intake chamber with low suction-side water levels	CG discharge tube Design with underfloor discharge for installation in covered intake chamber with low suction-side water levels	DG discharge tube Design with above floor discharge nozzle for installation in covered intake chamber with low suction-side water levels

²⁾ For information on the various designs (foundation measurements, intake chamber, etc.) refer to the general arrangement drawings.

4.7 Configuration and function




Fig. 5: Amacan with mixed flow impeller

1	Suction nozzle (bellmouth)	2	Impeller
3	Pump casing	4	Electric motor
5	Shaft	6	Bearing housing, drive end
7	Bearing, drive end	8	Bearing, pump end
9	Bearing housing, pump end	10	Shaft seal

Design The pump is designed with an axial fluid inlet and an axial outlet. The hydraulic system sits on the extended motor shaft. The shaft runs in common bearings.

Function The fluid enters the pump axially via a suction nozzle (bellmouth) (1) and is accelerated in a rotating flow by the rotating impeller (2). The required energy is transmitted from the electric motor (4) to the impeller (2) via the shaft (5). In the pump casing (3) the kinetic energy of the fluid is converted into pressure energy. The rotational movement diverts the fluid flow into a mixed flow. The shaft passage through the casing is sealed towards the fluid with a shaft seal (10). The shaft (5) runs in two rolling element bearings (7 and 8), which are supported by the lower bearing housing (9) and the upper bearing housing (6).

Sealing The pump is sealed by two bi-directional mechanical seals in tandem arrangement. A lubricant chamber in-between the seals ensures cooling and lubrication of the mechanical seals.

Monitoring equipment The pump sets are equipped with various sensors.

Standard

- Temperature monitoring of the motor
- Temperature monitoring at the lower bearing
- Temperature monitoring at the upper bearing
- Leakage monitoring of the mechanical seal system
- Leakage sensors in the motor space

Option

- Additional winding temperature monitoring with Pt100

4.8 Scope of supply

Depending on the model, the following items are included in the scope of supply:

- Pump set complete with power cables
- O-ring
- Back-up name plate

Optional accessories:

- Support rope
- Accessories for installing the cable guide:
 - Spacer
 - Turnbuckle
 - Support
 - Shackle
 - Cable clamps
- Cable support sleeves
- Discharge tube
- Flow-straightening vane to prevent floor vortices



NOTE

A separate name plate is included in KSB's scope of supply. Attach this name plate in a clearly visible position outside the place of installation, e.g. at the control panel, pipeline or mounting bracket.

4.9 Dimensions and weights

For dimensions and weights please refer to the name plate or data sheet of the pump set.

5 Installation at Site

5.1 Safety regulations

	 DANGER Improper installation in potentially explosive atmospheres Damage to the pump set! ▷ Comply with the applicable local explosion protection regulations. ▷ Observe the information given in the data sheet and on the pump/motor name plates.
	 DANGER Persons in the intake chamber during pump set operation Electric shock! Risk of injury! ▷ Never start up the pump set when there are persons in the intake chamber.
	 WARNING Impermissible solid objects (tools, screws/bolts or similar) in the pump sump/inlet tank during pump start-up Personal injury and damage to property! ▷ Check the pump sump/inlet tank for impermissible solid objects before flooding, and remove, if necessary.

5.2 Checks to be carried out prior to installation

5.2.1 Checking the structural requirements

All structural work required must have been prepared in accordance with the dimensions stated in the outline drawing / general arrangement drawing ..

5.2.2 Checking the operating data

Before inserting the pump set into the discharge tube, verify the data on the name plate against the data given in the purchase order and the system data.

Back-up name plate

KSB's scope of supply includes a separate name plate attached to the end of the pump cable which indicates the pump and motor data.

1. Attach this name plate in a clearly visible position outside the discharge tube, e.g. at the control cabinet, pipeline or mounting bracket.

5.2.3 Checking the lubricant of the mechanical seal

The lubricant chamber is filled at the factory with an environmentally-friendly, non-toxic lubricant.

Visual inspection for signs of oil leakage

1. If no oil leakage is visible in the area of the pump casing, impeller and transport holder, the lubricant chamber is filled properly.
2. If oil leakage is visible in the area of the pump casing, impeller and transport holder, top up the lubricant chamber.




Fig. 6: Visual inspection for signs of oil leakage

For topping up the lubricant chamber the pump set needs to be partly dismantled and reassembled.

Observe all safety instructions and carry out the following actions for dismantling/reassembly:

Table 7: Actions for dismantling/reassembly

Sequence	Action	See the following section
1	Placing the pump in a vertical position	(⇒ Section 3.2.2, Page 12)
2	Removing the bellmouth	(⇒ Section 7.5.3, Page 66)
3	Removing the impeller	(⇒ Section 7.5.4, Page 67)
4	Filling in the lubricant	(⇒ Section 7.4.1.4.2, Page 63)
5	Fitting the impeller	(⇒ Section 7.6.5, Page 77)
6	Fitting the bellmouth	(⇒ Section 7.6.6, Page 78)
7	Adjusting the clearance	

5.2.4 Checking the direction of rotation

	! WARNING Hands and/or foreign objects in the pump casing Risk of injuries, damage to the pump! ▷ Never insert your hands or any other objects into the pump. ▷ Check that the inside of the pump is free from any foreign objects. ▷ Verify that the transport lock has been removed. ▷ Take suitable precautions (e.g. wear safety goggles).
	! WARNING Improper handling when placing the pump set in a vertical/horizontal position Personal injury and damage to property! ▷ Use one or two pieces of lifting equipment, depending on the pump (set) size. ▷ Use appropriate means to secure the pump set against tilting, tipping over or rolling off. ▷ Maintain a safe distance during lifting operations (load may swing when being lifted). ▷ Use additional supports for the transport holder to secure it against tilting.
	! WARNING Improper positioning of pump set when checking the direction of rotation Personal injury and damage to property! ▷ Use appropriate means to secure the pump set against tilting or tipping over.

	CAUTION
	Pump set running dry Increased vibrations! Damage to mechanical seals and bearings! ▷ Never operate the pump set without the fluid to be handled for more than 60 seconds.

Check the direction of rotation before installing the pump set, i.e. in dry condition.

1. Place the pump set in a vertical position on a level surface and secure it sufficiently against tipping over.
2. Connect the pump set to the power supply and start it up.
3. Use one of the following options to check the direction of rotation:
 - ⇒ 1. Look down into the pump bowl and check that the impeller rotates clockwise.
 - ⇒ 2. Verify the direction of rotation of the impeller. The direction of rotation of the impeller must match the arrow indicating the direction of rotation on the pump casing.
4. If the impeller rotates in the wrong direction of rotation, check and correct the electrical connection and the control system if applicable. Then check the direction of rotation again.
5. If the direction of rotation is correct, mark which core ends match which of the terminals in the control cabinet.
6. Disconnect the pump set from the power supply and secure it against unintentional start-up.

	⚠ WARNING
	Unintentional starting of pump set Risk of injury by moving components and shock currents! ▷ Make sure that the pump set cannot be started up unintentionally. ▷ Always make sure the electrical connections are disconnected before carrying out work on the pump set.

5.3 Lowering the pump set into the discharge tube

	 DANGER Improper transport Danger to life from falling parts! Damage to the pump set! ▷ Use the attachment point provided for attaching the lifting accessory. ▷ Never lift the pump set by the electric cables. ▷ Use the lifting chain/rope included in the scope of supply exclusively for lowering or lifting the pump set into/out of the pump sump. ▷ Securely attach the lifting chain/rope to the pump and crane. ▷ Use tested, marked and approved lifting accessories only. ▷ Observe the regional transport regulations. ▷ Observe the documentation of the lifting accessory manufacturer. ▷ The load-carrying capacity of the lifting accessory must be higher than the weight indicated on the name plate of the pump set to be lifted. Take into account any additional system components to be lifted. ▷ Maintain a safe distance during lifting operations (load may swing when being lifted).
	 DANGER Improper installation in potentially explosive atmospheres Damage to the pump set! ▷ Comply with the applicable local explosion protection regulations. ▷ Observe the information given in the data sheet and on the pump/motor name plates.
	 WARNING Incorrect handling of the electric cable Personal injury and damage to property! ▷ Secure electric cables against falling down. ▷ Avoid electric cables being laid on surfaces without fastening. ▷ When moving the pump set keep at a safe distance to the electric cables.
	 WARNING People falling into the unsecured discharge tube Risk of personal injury! ▷ Take suitable precautions during the entire installation/dismantling process to protect people from falling into the open discharge tube. ▷ Fence off the work area appropriately.

5.3.1 Information for correct installation

The **flow-straightening vane** is **indispensable** for the inlet conditions of the pump set. It prevents the development of a submerged vortex (floor vortex) which could cause a drop in performance, for example. For optimum inlet conditions observe the following information:

1. Observe the structural requirements!

Install the flow-straightening vane concentrically below the discharge tube, see general arrangement drawing.




Fig. 7: Installation position of the flow-straightening vane

1	Flow-straightening vane	2	Discharge tube
3	Intake chamber		

2. Observe the installation position of the pump set!

Lower the pump set into the discharge tube with the anti-swirl baffles (2) in the bellmouth aligned with the flow-straightening vane (3).

Use the bail alignment of the pump set for orientation. The bail (1) is aligned with the anti-swirl baffles (2).




Fig. 8: Installation position of the pump set

1	Bail	2	Anti-vortex vanes
3	Flow-straightening vane		

5.3.2 Installing the pump set without support rope

	CAUTION		
	Incorrect installation Damage to the pump set! ▷ Verify that the pump set sits correctly on the bottom of the discharge tube.		




Fig. 9: Inserting the O-ring

Always refer to and comply with the general arrangement drawing/outline drawing when installing the pump set.

1. If O-ring 412.05 is supplied but not fitted, insert it into pump casing 101.
2. Attach the crane hook of the crane to the bail of the pump set.
3. Center the pump set above the discharge tube. Slowly lower the pump set into the discharge tube until it is seated in the recommended position.
(⇒ Section 5.3.1, Page 28)
4. Pull the cables up by hand. Fasten them to the sump construction with a cable support sleeve, if required. Do not lift the pump set out of its seat.




Fig. 10: Fastening the cable support sleeve

5.3.3 Installing the pump set with a support rope

Always refer to and comply with the general arrangement drawing/outline drawing when installing the pump set.

1. Prior to installing the pump set, visually inspect the support rope.
2. Do not exceed the permissible load-carrying capacity.




Fig. 11: X = indication of load-carrying capacity

59-24	Support rope
59-17.01	Shackle



CAUTION

Incorrect installation

Damage to the pump set!

- Verify that the pump set sits correctly on the bottom of the discharge tube.

	! WARNING Pump set drops during the installation or removal process Personal injury and damage to property! ▷ Never use the turnbuckle, shackle or discharge tube cover to lift the pump set. ▷ Always use lifting lug 59-47.
	NOTE Prior to fitting the turnbuckle, check that the corresponding split pin has not been cracked or chipped. If damaged, always use a new split pin.

- ✓ Suitably sized lifting equipment is available.
- ✓ The support rope has been visually inspected.
- ✓ The split pin of the turnbuckle has been checked for any damage.




Fig. 12: Inserting the O-ring

1. If O-ring 412.05 is supplied but not fitted, insert it into pump casing 101.




Fig. 13: Lifting and positioning the pump set

2. Secure the lifting chain or lifting rope (1) to the trolley (4) of the lifting equipment (2).
3. Attach the support rope (5) to the bail by its shackle.
For a galvanized shackle, secure the pin at the shackle with Loctite 243.
(⇒ Section 9.2, Page 88)
For a stainless steel shackle, undo and tighten the pin twice and secure it with Loctite 243.
4. Check that the support rope is arranged correctly.
⇒ The free lifting lug (6) has to point away from the pump set
5. Partially unwind the support rope and electric cables.
6. Lower the pump set into the discharge tube until the bail is in an accessible position, protruding from the discharge tube.
7. Securely cover the discharge tube except for a gap which allows work to continue.

8. Attach the first eyebolt of the support rope (5) to the hoisting rope (1) to securely position the pump set above the discharge tube.
9. Unclick the hook of the lifting equipment from the eyebolt of the support rope and run the lifting equipment to a higher level.




Fig. 14: Securing the control cable and power cable

10. Secure the control cable (7) and power cables (8) to the crane hook (3) of the lifting equipment with a manila rope (9).
11. Trim spacer (a) to fit between the two ferrules.




Fig. 15: Cross-section of the cable guide

12. Insert the support rope (f) and the control cable (c) into the spacer (a) and make sure that they are in their respective ducts.
13. Tighten the electric cables with the manila rope running over the crane hook.
14. Insert the power cables (b) into the hollows of the spacer (a) and, starting from the bottom, firmly clamp the power cables with cable clamps (d) covered by a plastic sheath (e).
15. In the area of the eyebolt between the rope sections, lay all electric cables in loops and fasten them to the rope section above.
16. Progressively lower the pump set into the discharge tube while securing the cable bundle with evenly spaced sheathed cable clamps.
17. Fit a heat shrink tube on any protruding sharp-edged rope ends (e.g. at the ferrule) to prevent any damage to the power cable and the control cable.




Fig. 16: Lowering the pump set

18. Finally, attach the support rope with shackle and turnbuckle to a suspension loop (provided in the discharge tube or structure). Secure the turnbuckle with a split pin. After inserting the split pin, bend over its two legs.
19. Tighten the turnbuckle until the cable bundle is tight but does not lift the pump off its seat.
20. Unclip the hook of the lifting equipment from the eyebolt, free the electric cables from the manila rope and route them to the control cabinet.
21. Attach the top loose eyebolt to the cable bundle to prevent noise and wear caused by chafing.
22. Remove the safety cover from the discharge tube and mount the discharge tube cover. Seal the cable entries if any!

5.3.4 Installing the pump set with a support rope and support spacer

Always refer to and comply with the general arrangement drawing/outline drawing when installing the pump set.

1. Prior to installing the pump set, visually inspect the support rope.
2. Do not exceed the permissible load-carrying capacity.




Fig. 17: X = indication of load-carrying capacity

59-24	Support rope
59-17.01	Shackle

	CAUTION
	Incorrect installation Damage to the pump set! ▶ Verify that the pump set sits correctly on the bottom of the discharge tube.
	WARNING
	Pump set drops during the installation or removal process Personal injury and damage to property! ▶ Never use the turnbuckle, shackle or discharge tube cover to lift the pump set. ▶ Always use lifting lug 59-47.
	NOTE
	Prior to fitting the turnbuckle, check that the corresponding split pin has not been cracked or chipped. If damaged, always use a new split pin.

- ✓ Suitably sized lifting equipment is available.
- ✓ The support has been supplied pre-assembled and is available for use.
- ✓ The support rope has been visually inspected.
- ✓ The split pin of the turnbuckle has been checked for any damage.




Fig. 18: Inserting the O-ring

1. If O-ring 412.05 is supplied but not fitted, insert it into pump casing 101.




Fig. 19: Lifting and positioning the pump set

2. Secure the lifting chain or rope (1) to the trolley (4) of the lifting equipment (2).
3. Attach the support rope (5) to the bail by its shackle. Check that the support rope is arranged with the free lifting lug (6) pointing away from the pump set.
4. Partially unwind the support rope and connection cables.
5. Lower the pump set into the discharge tube until the bail is in an accessible position, protruding from the discharge tube.
6. Securely cover the discharge tube except for a gap which allows work to continue.
7. Attach the first lifting lug of the support rope (5) to the lifting rope (1) to securely position the pump set above the discharge tube.
8. Unclick the hook of the lifting equipment from the lifting lug of the support rope and run the lifting equipment to a higher level.




Fig. 20: Securing the control and power cables

9. Secure the control cable (7) and power cables (8) to the crane hook (3) of the lifting equipment with a manila rope (9).
10. Trim the spacer (a) to fit between the two ferrules.




Fig. 21: Cross-section of the cable guide

11. Insert the support rope (f) and the control cable (c) into the spacer (a) and make sure that they are in their respective ducts.
12. Tighten the cables with the manila rope running over the crane hook.
13. Insert the power cables (b) into the hollows of the spacer (a) and, starting from the bottom, firmly clamp the power cables with cable clamps (d) covered by a plastic sheath (e).
14. Progressively lower the pump set into the discharge tube while securing the cable bundle with evenly spaced sheathed cable clamps.
15. In the area of the lifting lug between the rope sections, lay all cables in loops and fasten them to the rope section above.
16. Fit a heat shrink tube on any protruding sharp-edged rope ends (e.g. at the ferrule) to prevent any damage to the power and control cables.
17. Trim the spacer (a) to suit the position of support 59-7 at the support rope (f) and the type of installation. Insert the support rope and control cable (c).
18. Insert the power cables (b) into the hollows of the spacer (a) and firmly clamp the power cables with cable clamps (d).




Fig. 22: Support rope with support, dimensions in [mm]

*) Depending on the cable cross-section,

**) For 1 rope or 3 ropes = 1.181 inch [30 mm]

Table 8: Key to the symbols

Symbol	Key
	Always secure screwed connections marked with this symbol with Loctite 243 .

19. Clamp support 59-7 with clamping element 81-51 to the support rope (f).
20. Undo the screwed connection at clamping element 81-51.
21. Place clamp 81-39 of the clamping element around the support rope.

22. Fasten plate 185 and clamp 81-39 of the GFRP rod to rope clamp 81-39 with hexagon head bolts 901, discs 550 and cap nuts 920. Tighten the connection and secure it with Loctite 243.

**NOTE**

The support must be firmly clamped to the support rope, and the GFRP rod must be firmly clamped to the support. If necessary, pad out clamps 81-39.

23. Trim the spacer to fit between the two ferrules and accommodate the support.
24. Guide the power cables and control cable along the support to the next cable clamp. Pull them taut and secure them with the clamp.




Fig. 23: Lowering the pump set

25. Progressively lower the pump set into the discharge tube. Secure the cable bundle with cable clamps.
26. Finally, attach the support rope with shackle and turnbuckle to a suspension loop (provided in the discharge tube or structure). Secure the turnbuckle with a split pin. After inserting the split pin, bend over its two legs.
27. Tighten the turnbuckle until the cable bundle is tight but does not lift the pump off its seat.
28. Unclip the hook of the lifting equipment from the lifting lug, free the electric cables from the manila rope and route them to the control cabinet.

29. Attach the top loose lifting lug to the cable bundle to prevent noise and wear caused by chafing.
30. Remove the safety cover from the discharge tube and mount the discharge tube cover.
31. Seal the cable entries if any.

5.4 Electrical system

5.4.1 Information for planning the control system

For the electrical connection of the pump set observe the wiring diagrams.

(⇒ Section 9.3, Page 90)

The pump set is supplied with power cables; it is wired for DOL starting.

	NOTE When laying a cable between the control system and the pump set's connection point, verify that the number of cores is sufficient for the sensors. A minimum cross-section of 1.5 mm² is required.
---	---

The motors can be connected to electrical low-voltage grids with rated voltages and voltage tolerances to IEC 60038. The permissible tolerances must be observed.

5.4.1.1 Setting the overload protection device

1. Protect the pump set against overloading by a thermal time-lag overload protection device in accordance with IEC 60947 and local regulations.
2. Set the overload protection device to the rated current specified on the name plate.

5.4.1.2 Level control

	! DANGER Pump set running dry Explosion hazard! ▷ Never allow a pump set to run dry.
--	---

	CAUTION Fluid level below the specified minimum Damage to the pump set by cavitation! ▷ Never allow the fluid level to drop below the specified minimum.
---	---

Automatic operation of the pump set in a sump / tank requires the use of level control equipment.

Observe the minimum fluid level indicated. (⇒ Section 6.2.4.3, Page 49)

5.4.1.3 Operation on a frequency inverter

The pump set is driven by an induction machine to IEC 60034-12 designed for fixed speed operation. In accordance with IEC 60034-25, Section 18, the pump set is suitable for operation on a frequency inverter.

	NOTE For pump sets with rated voltages exceeding 500 V, a dv/dt filter should be fitted at the output of the frequency inverter to reduce the rate of voltage rise to the limits specified in IEC 60034-25, Section 18. Otherwise a considerably reduced service life of the insulation system has to be expected.
---	---

	! DANGER Operation outside the permitted frequency range Explosion hazard! ▷ Never operate an explosion-proof pump set outside the specified range.
---	--

	! DANGER
	Incorrect selection and setting of the frequency inverter Explosion hazard! ▷ Observe the following information on selecting and setting a frequency inverter.

Selection When selecting a frequency inverter, check the following details:

- Data provided by the manufacturer
- Electrical data of the pump set, particularly the rated current
- Only voltage intermediate-circuit inverters (VSI) with pulse width modulation (PWM) and carrier frequencies between 1 and 16 kHz are suitable.

Setting Observe the following instructions for setting a frequency inverter:

- Set the current limit to max. 1.2 times the rated current. The rated current is indicated on the name plate.

Start-up Observe the following instructions for starting up a frequency inverter:

- Ensure short start ramps (maximum 5 seconds).
- Only start speed-controlled operation after 2 minutes at the earliest. Pump start-up with long start ramps and low frequency may cause clogging.

Operation Observe the following limits when operating the pump set on a frequency inverter:

- Only utilize up to 95 % of the rated power P_2 indicated on the name plate.
- Frequency range 30 to 60 Hz

Electromagnetic compatibility Operation on a frequency inverter produces interference emissions whose level varies depending on the inverter used (type, interference suppression, make). To prevent the drive system, consisting of a submersible motor and a frequency inverter, from exceeding any given limits always observe the EMC information provided by the inverter manufacturer. If the inverter manufacturer recommends a shielded power cable, make sure to use a submersible motor pump with shielded power cables.

Interference immunity The submersible motor pump generally meets interference immunity requirements. For monitoring the sensors installed the operator must ensure sufficient interference immunity by appropriately selecting and laying the power cables in the plant. No modifications are required on the power/control cable of the submersible motor pump. Suitable analyzing devices must be selected. This applies in particular to the leakage sensor inside the motor.

5.4.1.4 Sensors

	! DANGER
	Operating an incompletely connected pump set Damage to the pump set! ▷ Never start up a pump set with incompletely connected power cables or non-operational monitoring devices.
	CAUTION
	Incorrect connection Damage to the sensors! ▷ Observe the limits stated in the following sections of this manual when connecting the sensors.

The pump set features sensors that avoid hazards and damage to the pump set.



NOTE

Reliable and safe operation of the pump within the scope of our warranty is only possible if the sensor signals are properly analyzed as stipulated in this manual.

All sensors are located inside the pump set and are connected to the sensor cable.

For information on wiring and core marking see (⇒ Section 9.3, Page 90)

The individual sensors and the limit values to be set are described in the following sections.




Fig. 24: Sensor positions

Position	Sensor	Standard	Optional
1	Leakage inside the motor (connection and winding space)	X	-
2	Bearing temperature (upper bearing assembly)	-	X
3	Bearing temperature (lower bearing assembly)	X	-
4	Mechanical seal leakage	X	-
5	Vibration sensor	-	X
6	Motor temperature (PTC)	X	-
7	Motor temperature (Pt100)	-	X

5.4.1.4.1 Motor temperature



DANGER

Insufficient cooling

Explosion hazard!

Winding damage!

- ▷ Never operate a pump set without operational temperature monitoring.
- ▷ For explosion-proof pump sets use a thermistor tripping unit with manual reset.

Three series-connected thermistors (PTC) at terminals 10 and 11 monitor the winding temperature.

Use a thermistor tripping unit with manual reset.


Pt100 resistance thermometer

As an option, in addition to the above, the motor can be fitted with Pt100 resistance thermometers in the winding. These can be used for reading the motor temperature (sensor circuit maximum 6 V/2 mA).

	CAUTION
	Temperature monitoring equipment not properly connected Winding damage! ▶ Never use the Pt100 resistance thermometers as a sole means of monitoring the motor temperature.

5.4.1.4.2 Leakage inside the motor

	⚠ DANGER
	Incorrect monitoring of leakage electrode Explosion hazard! Danger of death from electric shock! ▶ Voltages must be < 30 V AC and tripping currents < 0.5 mA.



An electrode fitted inside the motor monitors the winding space (B2) for leakage. This electrode must be connected to an electrode relay (core marked 9). Tripping of the electrode relay must result in the pump set cutting out.

The electrode relay (K1) must trip at a resistance between 3 and 60 kΩ.

5.4.1.4.3 Mechanical seal leakage

The chamber for mechanical seal leakage is equipped with a float switch (core identification 3 and 4). The contact (maximum 250 V~/2 A) opens when leakage is detected in the leakage chamber. Opening of the contact shall trigger an alarm signal.




Fig. 25: Float switch

5.4.1.4.4 Bearing temperature

The bearings of the pump set are equipped with bearing temperature sensors. The two sensors are Pt100 resistance thermometers (core identification 15 and 16). They must be connected to a temperature control device with a Pt100 input and two separate outputs for two different switching points (sensor circuit maximum 6 V/2 mA).

Set the following limits:

- Alert at 230 °F [110 °C]
- Cut-out of the pump set at 266 °F [130 °C]

5.4.2 Connection to power supply

	! DANGER Electrical connection work by unqualified personnel Danger of death from electric shock! ▷ Always have the electrical connections installed by a trained electrician. ▷ Observe the EN 61557 regulations as well as any locally applicable regulations.
	! WARNING Incorrect connection to the mains Damage to the power supply network, short circuit! ▷ Observe the technical specifications of the local energy supply companies.
	CAUTION Improper routing of power cables Damage to the power cables! ▷ Never move the power cables at temperatures below -13 °F [-25 °C]. ▷ Never kink or crush the power cables. ▷ Never lift the pump set by the power cables. ▷ Adjust the length of the power cables to the site requirements.
	CAUTION Motor overload Damage to the motor! ▷ Protect the motor by a thermal time-lag overload protection device in accordance with IEC 60947 and local regulations.

For the electrical connection observe the wiring diagrams (⇒ Section 9.3, Page 90) in the Annex and the information for planning the control system (⇒ Section 5.4.1, Page 39) .

The pump set is supplied with power cables.

Always use all electric cables provided and connect all marked cores of the sensor cable.

	! DANGER Incorrect connection Explosion hazard! ▷ The connection point of the cable ends must be located outside hazardous areas or in an area approved for electrical equipment.
---	--

	! DANGER Operating an incompletely connected pump set Damage to the pump set! ▷ Never start up a pump set with incompletely connected power cables or non-operational monitoring devices.
	! DANGER Using damaged power cables Danger of death from electric shock! ▷ Never connect damaged power cables. ▷ Visually inspect the power cable before connecting it. ▷ Replace the power cable, if it is damaged.
	CAUTION Flow-induced motion Damage to the power cable! ▷ Run the power cable upwards without slack.




Fig. 26: Fastening the power cable

1. Run the power cables directly upwards without slack, and fasten.
2. Only remove the protective caps from the power cables immediately before connecting the cables.
3. If necessary, adjust the length of the power cables to the site requirements.
4. After shortening the cables, correctly re-affix the markings of the individual cores at the cable ends.

Potential equalization The pump set does not have an external PE connection (risk of corrosion).

	! DANGER Incorrect connection Explosion hazard! ▷ Explosion-proof pump sets installed in a tank must never be retrofitted with an external potential equalization connection!
---	---

**DANGER****Touching the pump set during operation**

Electric shock!

- ▷ Make sure that the pump set cannot be touched during operation.

6 Commissioning/Start-up/Shutdown

6.1 Commissioning/start-up

6.1.1 Prerequisites for commissioning/start-up

	 DANGER Operating the pump set without protective equipment Electric shock! Risk of injury! Danger of death from drowning! ▷ Never start up the pump set without special protective equipment when there are persons in the tank. ▷ If persons come into contact with the fluid handled during pump operation (e.g. in sports facilities and leisure parks), the plant designer/operator must comply with the legal requirements. ▷ Provide special electrical and mechanical protective equipment compliant with the legal regulations.
	 WARNING Operating the pump set without mechanical protective equipment Risk of injury from solid matter in the fluid handled! ▷ If persons come into contact with the fluid handled during pump operation (e.g. in sports facilities and leisure parks), install mechanical protective equipment (e.g. a screen) on the discharge side of the pump set.
	 WARNING People falling into the unsecured discharge tube Risk of personal injury! ▷ Take suitable precautions during the entire installation/dismantling process to protect people from falling into the open discharge tube. ▷ Fence off the work area appropriately.

Before commissioning/starting up the pump set, make sure that the following conditions are met:

- The lubricant has been checked.
- The direction of rotation has been checked.
- The pump set has been properly connected to the power supply and is equipped with all protection devices.
- The pump set has been installed in the discharge tube as described in this manual.
- The minimum fluid level has been reached.
- After prolonged shutdown of the pump (set), the activities required for returning the equipment to service have been carried out. (⇒ Section 6.4, Page 50)
- Safety-relevant protective equipment must be installed and fully functional.

6.1.2 Start-up

	⚠ DANGER Operating the pump set without protective equipment Electric shock! Risk of injury! Danger of death from drowning! ▷ Never start up the pump set without special protective equipment when there are persons in the tank. ▷ If persons come into contact with the fluid handled during pump operation (e.g. in sports facilities and leisure parks), the plant designer/operator must comply with the legal requirements. ▷ Provide special electrical and mechanical protective equipment compliant with the legal regulations.
---	---

	CAUTION Re-starting while motor is still running down Damage to the pump set! ▷ Do not re-start the pump set before it has come to a standstill. ▷ Never start the pump set while the pump is running in reverse.
---	--

✓ The fluid level is sufficiently high.

	CAUTION Start-up against a closed shut-off element Damage to the pump set! ▷ Never start up the pump set against a closed shut-off element.
---	---

1. Fully open the discharge line shut-off element, if any.
2. Start up the pump set.

6.2 Operating limits

	⚠ DANGER Non-compliance with operating limits Damage to the pump set! ▷ Comply with the operating data indicated in the data sheet. ▷ Avoid operation below Q_{min}. ▷ Never operate an explosion-proof pump set at ambient temperatures or fluid temperatures exceeding those specified in the data sheet and/or on the name plate. ▷ Never operate the pump set outside the limits specified below.
---	---

6.2.1 Operation on the power supply mains

The maximum permissible deviation in supply voltage is $\pm 10\%$ of the rated voltage.
The voltage difference between the individual phases must not exceed 1 %.

6.2.2 Frequency of starts

	CAUTION
	Excessive frequency of starts Damage to the motor! ▸ Never exceed the specified frequency of starts.

To prevent high temperature increases in the motor and excessive loads on the motor, sealing elements and bearings, the frequency of starts shall not exceed 10 start-ups per hour.

These values apply to mains start-up (DOL or with autotransformer or soft starter). These limits do not apply to operation on a frequency inverter.

	CAUTION
	Re-starting while motor is still running down Damage to the pump set! ▸ Do not re-start the pump set before it has come to a standstill. ▸ Never start the pump set while the pump is running in reverse.

6.2.3 Operation on a frequency inverter

	! DANGER
	Operation outside the permitted frequency range Explosion hazard! ▸ Never operate the pump set outside the specified range.

Frequency inverter operation of the pump set is permitted in the frequency range from 30 to 60 Hz.

6.2.4 Fluid handled

6.2.4.1 Fluid temperature

The pump set is designed for transporting liquids. The pump set is not operational under freezing conditions.

	CAUTION
	Danger of freezing! Damage to the pump set! ▸ Drain the pump set or protect it against freezing.

Refer to the maximum permissible fluid temperature and ambient temperature indicated on the name plate and/or in the data sheet.

6.2.4.2 Density of the fluid handled

The power input of the pump set changes in proportion to the density of the fluid handled.

	CAUTION
	Impermissibly high density of fluid handled Motor overload! ▷ Observe the information on fluid density in the data sheet. ▷ Make sure the motor has sufficient power reserves.

6.2.4.3 Minimum level of fluid handled

	CAUTION
	Fluid level below the specified minimum Damage to the pump set by cavitation and air-entraining vortices! ▷ Never allow the fluid level to drop below the specified minimum.

The pump set is ready for operation when the fluid level has reached dimension "t₁" as a minimum (see the corresponding general arrangement drawing).




Fig. 27: Example: Minimum level of fluid handled

6.2.4.4 Abrasive fluids

Do not exceed the maximum permissible solids content specified in the data sheet. When the pump handles fluids containing abrasive substances, increased wear of the hydraulic system and shaft seal is to be expected. In this case, reduce the commonly recommended inspection intervals.

6.3 Shutdown/storage/preservation

6.3.1 Shutdown

	CAUTION
	Uncontrolled backflow of the fluid from the riser Damage to the pump set! ▷ Prevent any uncontrolled backflow of the fluid handled with suitable means. ▷ Control the fluid backflow, e.g. by throttling the gate valve in the discharge line.

6.3.2 Measures to be taken for shutdown

	 DANGER Electrical connection work by unqualified personnel Danger of death from electric shock! ▷ Always have the electrical connections installed by a trained electrician. ▷ Observe the EN 61557 regulations as well as any locally applicable regulations.
	 WARNING Unintentional starting of pump set Risk of injury by moving components and shock currents! ▷ Make sure that the pump set cannot be started up unintentionally. ▷ Always make sure the electrical connections are disconnected before carrying out work on the pump set.
	 WARNING Fluids handled, consumables and operating supplies which are hot or pose a health hazard Risk of personal injury! ▷ Observe all relevant laws. ▷ When draining the fluid take appropriate measures to protect persons and the environment. ▷ Decontaminate pumps which handle fluids posing a health hazard.
	CAUTION Danger of frost/freezing Damage to the pump set! ▷ If there is any danger of frost/freezing, remove the pump set from the fluid handled and clean, preserve and store it.

The pump set remains installed

- ✓ Make sure sufficient fluid is available for the functional check run of the pump set.

1. For prolonged shutdown periods, start up the pump set regularly once every three months. Let it run for approximately one minute.
This will prevent the formation of deposits within the pump and the pump intake area.

The pump (set) is removed from the pipe and stored

- ✓ All safety regulations are observed.

1. Clean the pump set.
2. Spray-coat the inside wall of the pump casing and, in particular, the impeller clearance areas with a preservative.

6.4 Returning to service

For returning the pump set to service, observe the items on commissioning/start-up. (⇒ Section 6.1, Page 46)

Refer to and comply with the operating limits.

For returning the equipment to service after pump set storage also follow the instructions for maintenance/inspection.

	 WARNING Failure to re-install or re-activate protective equipment/devices Risk of personal injury from moving parts or escaping fluid! ▷ As soon as the work is completed, re-install and/or re-activate any safety-relevant devices and protective devices.
	NOTE On pumps/pump sets older than 5 years we recommend replacing all elastomer seals.

7 Servicing/Maintenance

7.1 Safety regulations

The operator ensures that all maintenance, all inspections and all installation work is performed by authorized, qualified specialist personnel who are thoroughly familiar with the manual.

	 DANGER Improper lifting/moving of heavy assemblies or components Danger to life from falling parts! Damage to the pump set! ▷ Use suitable transport devices, lifting equipment and lifting tackle to move heavy assemblies or components. ▷ Use the attachment point provided for attaching the lifting accessory. ▷ Never lift the pump set by the electric cables. ▷ Use the lifting chain/rope included in the scope of supply exclusively for lowering or lifting the pump set into/out of the pump sump. ▷ Securely attach the lifting chain/rope to the pump and crane. ▷ Use tested, marked and approved lifting accessories only. ▷ Observe the regional transport regulations. ▷ Observe the documentation of the lifting accessory manufacturer. ▷ The load-carrying capacity of the lifting accessory must be higher than the weight indicated on the name plate of the pump set to be lifted. Take into account any additional system components to be lifted. ▷ Maintain a safe distance during lifting operations (load may swing when being lifted).
	 DANGER Risk of falling when working at great heights Danger to life by falling from great heights! ▷ Do not step onto the pump (set) during installation work or dismantling work. ▷ Pay attention to safety equipment, such as railings, covers, barriers, etc. ▷ Observe the applicable local occupational safety regulations and accident prevention regulations.
	 DANGER Electrical connection work by unqualified personnel Danger of death from electric shock! ▷ Always have the electrical connections installed by a trained electrician. ▷ Observe the EN 61557 regulations as well as any locally applicable regulations.
	 WARNING Fluids handled, consumables and operating supplies which are hot or pose a health hazard Risk of personal injury! ▷ Observe all relevant laws. ▷ When draining the fluid take appropriate measures to protect persons and the environment. ▷ Decontaminate pumps which handle fluids posing a health hazard.

	⚠ WARNING Unintentional starting of pump set Risk of injury by moving components and shock currents! ▷ Make sure that the pump set cannot be started up unintentionally. ▷ Always make sure the electrical connections are disconnected before carrying out work on the pump set.
	⚠ WARNING Hands, other body parts or foreign objects in the impeller or intake area Risk of injury! Damage to the submersible motor pump! ▷ Never insert your hands, other body parts or foreign objects into the impeller and/or impeller intake area. ▷ Always make sure that the electrical connections are disconnected before checking that the impeller can rotate freely.
	⚠ WARNING Hot surface Risk of personal injury! ▷ Allow the pump set to cool down to ambient temperature.
	⚠ WARNING Improper lifting/moving of heavy assemblies or components Personal injury and damage to property! ▷ Use suitable transport devices, lifting equipment and lifting tackle to move heavy assemblies or components.
	⚠ WARNING Insufficient stability Risk of crushing hands and feet! ▷ During assembly/dismantling, secure the pump (set)/pump parts against tilting or tipping over.

A regular maintenance schedule will help avoid expensive repairs and contribute to trouble-free, reliable operation of the pump (set) with a minimum of maintenance expenditure and work.

	NOTE All maintenance work, service work and installation work can be carried out by KSB Service or authorized workshops. Find your contact in the attached Addresses booklet or visit https://www.ksb.com/en-global/contact.
---	---

Never use force when dismantling and reassembling the pump set.

7.2 Servicing/inspection

KSB recommends the following regular maintenance schedule:

Table 9: Overview of maintenance work

Maintenance interval	Maintenance work	For details see ...
First check after at least 6 months; interval can be extended to 12 months (in sports facilities and leisure parks)	Visually inspect for corrosion.	(⇒ Section 7.3.6, Page 59)
Every 4000 hours, at least once a year	Measure the insulation resistance.	(⇒ Section 7.2.1.1, Page 54)
Every 8000 hours, at least every 3 years	Check the cable bundle.	(⇒ Section 7.3.3, Page 57)
	Check the ground conductor.	(⇒ Section 7.3.4, Page 57)
	Check the sensors.	(⇒ Section 7.2.1.2, Page 54)
	Check the mechanical seal leakage.	(⇒ Section 5.2.3, Page 24)
	Change the lubricant.	
Every 16,000 hours, at least every 5 years	Lubricate the rolling element bearings.	
	General overhaul	

On pump sets with sacrificial anodes, the sacrificial anodes must initially be checked after 6 months. If necessary, the sacrificial anodes must be replaced. If the sacrificial anodes show little wear, the maintenance interval can be extended to 12 months.

7.2.1 Inspection work

7.2.1.1 Measuring the insulation resistance

Measure the insulation resistance of the motor winding during annual maintenance work.

- ✓ The pump set has been disconnected in the control cabinet.
- ✓ Use an insulation resistance measuring device.
- ✓ The maximum measuring voltage is 500 V (maximum permissible voltage 1000 V).
 1. Measure the winding to chassis ground.
To do so, connect all winding ends together.
 2. Measure the winding temperature sensor to chassis ground.
To do so, connect all core ends of the winding temperature sensors together and connect all winding ends to chassis ground.
- ⇒ The insulation resistance of the core ends to chassis ground must not be lower than 1 MΩ.
If the resistance measured is lower, power cable and motor resistance must be measured separately. Disconnect the power cable from the motor for this purpose.



NOTE

If the insulation resistance of the power cable is lower than 1 MΩ, the power cable is defective and must be replaced.



NOTE

If the insulation resistances measured on the motor are too low, the winding insulation is defective. The pump set must not be returned to service in this case.

7.2.1.2 Checking the sensors



CAUTION

Excessive test voltage

Damage to the sensors!

- ▷ Use a commercially available ohmmeter to measure the resistance.

The tests described below measure the resistance at the core ends of the control cable. The actual sensor function is not tested.

Temperature sensors in the motor winding

Table 10: Resistance measurement

Measurement between terminals ...	Resistance
	[Ω]
10 and 11	200 - 1000
31 and 32 ³⁾	100 - 120

If the specified tolerances are exceeded, disconnect the connection cable at the pump set and repeat the check inside the motor.

If the tolerances are exceeded here, too, the motor part must be opened and overhauled. The temperature sensors are fitted in the stator winding and cannot be replaced.

If the sensors are defective, use the back-up sensors provided at the same place in the stator winding.

Leakage sensor in the motor

Table 11: Resistance measurement of the leakage sensor in the motor

Measurement between terminals ...	Resistance
	[kΩ]
9 and ground conductor (PE)	> 60

Lower resistance values would suggest water ingress into the motor. In this case the motor section must be opened and serviced.

Float switch (mechanical seal leakage)

Table 12: Resistance measurement of the float switch

Measurement between terminals ...	Resistance
	[Ω]
3 and 4	< 1

If the readings suggest an open switch, check for mechanical seal leakage.

Bearing temperature sensor

Table 13: Resistance measurement bearing temperature

Measurement between terminals ...	Resistance
	[Ω]
15 and 16	100 to 120
16 and 17	100 to 120

If the measured value is within the permissible tolerance range and the tripping unit of the pump temperature sensor has tripped, the rolling element bearings must be checked and replaced, if required.

7.3 Removing the pump set

7.3.1 Removing the pump set

	 DANGER
	Insufficient preparation of work on the pump (set) Risk of injury! ▷ Properly shut down the pump set. ▷ Close the shut-off elements in the suction line and discharge line. ▷ Drain the pump and release the pump pressure. ▷ Shut off any auxiliary feed lines. ▷ Allow the pump set to cool down to ambient temperature.

³ Optional

	⚠ WARNING Incorrect handling of the electric cable Personal injury and damage to property! ▷ Secure electric cables against falling down. ▷ Avoid electric cables being laid on surfaces without fastening. ▷ When moving the pump set keep at a safe distance to the electric cables.
	⚠ WARNING People falling into the unsecured discharge tube Risk of personal injury! ▷ Take suitable precautions during the entire installation/dismantling process to protect people from falling into the open discharge tube. ▷ Fence off the work area appropriately.
	⚠ WARNING Turnbuckle and shackle are not suitable for lifting the pump set. Risk of personal injury! Damage to the pump set! ▷ Always use the eyebolts of the support rope to lift the pump set.

- ✓ The power cables have been disconnected and secured against accidental start-up.
- ✓ The discharge tube is open; its opening is securely covered except for a gap allowing work to continue.
- ✓ Suitable lifting equipment is available.
 1. Attach the lifting chain or lifting rope to the trolley.
 2. Free the uppermost lifting lug from the cable bundle, attach it to the crane hook and run the lifting equipment to a higher level.
 3. Open and disconnect the turnbuckle.

	NOTE Loose parts must not fall into the pump sump!
---	---

4. Pull the pump set up until it reaches the second lifting lug of the cable bundle.
5. Attach the lifting chain or lifting rope with the shackle to the first lifting lug (together with the crane hook).
6. Unclip the crane hook and attach it to the second lifting lug.
7. Pull the pump set up until it reaches the third lifting lug. Free the lifting chain or lifting rope from the first lifting lug and attach it to the third lifting lug.
8. Pull the pump set up until it reaches the fourth lifting lug. Unclip the crane hook and attach it to the fourth lifting lug.
9. Repeat this procedure until the pump bail is located above the discharge tube, then attach it to the crane hook.
10. Remove the safety cover from the discharge tube.
11. Extract the pump set from the discharge tube, move it sideways and place it down.

	 WARNING Pump set tilting Risk of squashing hands and feet! ▷ Suspend or support the pump set.
	CAUTION Improper storage Damage to the power cables! ▷ Support the power cables at the cable entry to prevent permanent deformation. ▷ Protect the core ends against humidity.

12. Do not disconnect the pump set from the hook of the lifting equipment to prevent the pump set from tipping over.

13. Clean the pump set (e.g. with water).

14. Collect and properly dispose of any cleaning liquid.

7.3.2 Drainage/cleaning

	 WARNING Fluids handled, consumables and operating supplies which are hot or pose a health hazard Hazard to persons and the environment! ▷ Collect and properly dispose of the flushing fluid and of any residues of the fluid handled. ▷ Wear safety clothing and a protective mask if required. ▷ Observe all legal regulations on the disposal of fluids posing a health hazard.
---	--

1. Always flush the pump if it has been used for handling noxious, explosive, hot or other hazardous fluids.

2. Always flush and clean the pump before transporting it to the workshop. Always complete and enclose a certificate of decontamination when returning the pump set. (⇒ Section 11, Page 139)

7.3.3 Checking the cable bundle

When removing the pump set from the discharge tube check the support rope and attachment (shackle) and all electric cables for any damage. In addition, observe the operating manual of the lifting accessories. Replace any damaged components by original spare parts.

Longer cable bundles must be dismantled:

1. Undo the cable clamps.
2. Remove the spacer.
3. Roll up the power cables and place them next to the pump set.
4. Undo the shackle to separate the support rope from the pump set.

7.3.4 Checking the ground conductor

1. Measure the resistance between ground conductor and chassis ground. The resistance must be lower than 1 Ω.
2. Replace any damaged components by original spare parts.

	⚠ DANGER Defective ground conductor Electric shock! ▷ Never switch on a pump set with a defective ground conductor.
---	--

7.3.5 Checking the mechanical seal leakage

	⚠ WARNING Fluids handled, consumables and operating supplies which are hot or pose a health hazard Hazard to persons and the environment! ▷ Collect and properly dispose of the flushing fluid and of any residues of the fluid handled. ▷ Wear safety clothing and a protective mask if required. ▷ Observe all legal regulations on the disposal of fluids posing a health hazard.
---	---

	⚠ WARNING Excess pressure inside the pump set Risk of personal injury when opening the pump set! ▷ Be careful when opening the inner chambers. Balance the pressure.
---	---

	NOTE Slight wear of the mechanical seal is unavoidable. This will be aggravated by abrasive substances contained in the fluid handled.
---	--

Checking the leakage chamber serves to assess the function of the drive-end mechanical seal.




Fig. 28: Checking the leakage chamber

Table 14: Key to the symbols

Symbol	Key
	Always apply a liquid sealant (e.g. Hylomar SQ32M) to sealing surfaces marked with this symbol.

- ✓ A suitable container for the leakage is available.
 - ✓ The pump set is positioned horizontally on a level surface and is secured against rolling away.
1. Place the container underneath screw plug 903.02.
 2. Remove screw plug 903.02 and joint ring 411.02.
 3. Screw in a sufficiently long tube (1) with G 1/2 thread.

4. Carefully rotate the pump set until the opening of the leakage chamber points downwards.
 - ⇒ If there is no leakage or only a small amount (less than 0.32 quart [0.3 liters]) after several years of operation, the mechanical seals are working properly. If the leakage exceeds 0.32 quart [0.3 liters], the mechanical seals are defective and must be replaced.
5. Unscrew and remove the tube (1).
6. Re-insert and tighten screw plug 903.02 with new joint ring 411.02.

7.3.6 Visually inspecting for corrosion

- ✓ The pump set has been removed from the system.
 1. Conduct a visual inspection of the pump set.
 - ⇒ Clearly visible corrosion: Replace defective components and check corrosion protection.
 - ⇒ No visible corrosion: Extend visual inspection interval to 12 months.

7.4 Lubrication and lubricant change

7.4.1 Lubricating the mechanical seal

	 DANGER Excessive temperatures at the shaft seal Explosion hazard! Damage to the pump set! ▷ Regularly check the condition of the lubricant in the lubricant chamber of the mechanical seal. Top it up if required.
--	--

The mechanical seal is supplied with lubricant from the lubricant chamber.

7.4.1.1 Intervals

Replace the lubricant every 8000 operating hours but at least every 3 years.

7.4.1.2 Lubricant quality

The lubricant chamber is filled at the factory with environmentally friendly, non-toxic lubricant (unless otherwise specified by the customer).

The following lubricants can be used to lubricate the mechanical seals:

Recommended lubricant quality

Alternative

- Environmentally friendly, non-toxic white oil of medical quality
- Thin-bodied paraffin oil, non-toxic
- Water / propylene glycol mixture with corrosion inhibitors for frost protection down to -4 °F [-20 °C].

Table 15: Lubricant quality

Description	Properties	
Paraffin oil or white oil	Kinematic viscosity at 104 °F [40 °C]	< 0.065 ft/s ² [< 20 mm/s ²]
	Flash point (to Cleveland)	> 320 °F [> 160 °C]
	Solidification point (pour point)	< 5 °F [< -15 °C]

	! WARNING
	Contamination of fluid handled by lubricant Hazard to persons and the environment! ▷ Using machine oil is only permitted if the oil is disposed of properly.

7.4.1.3 Lubricant quantity

Table 16: Lubricant quantity [l] depending on size

Size	Lubricant quantity	
	[quart]	[l]
650 - 364	1,69	1,6
650 - 365	1,69	1,6
650 - 404	1,69	1,6
650 - 405	1,69	1,6
800 - 505	1,9	1,8

7.4.1.4 Changing the lubricant

	! WARNING
	Lubricants posing a health hazard and/or hot lubricants Hazard to persons and the environment! ▷ When draining the lubricant take appropriate measures to protect persons and the environment. ▷ Wear safety clothing and a protective mask if required. ▷ Collect and dispose of any lubricants. ▷ Observe all legal regulations on the disposal of fluids posing a health hazard.
	! WARNING
	Excess pressure inside the pump set Risk of personal injury when opening the pump set! ▷ Be careful when opening the inner chambers. Balance the pressure.
	! WARNING
	Improper handling when placing the pump set in a vertical/horizontal position Personal injury and damage to property! ▷ Select suitable lifting equipment for the size of the pump. ▷ Use appropriate means to secure the pump set against tilting, tipping over or rolling off. ▷ Maintain a safe distance during lifting operations (load may swing when being lifted). ▷ Use additional supports for the transport holder to secure it against tilting.

7.4.1.4.1 Draining the lubricant



! WARNING

Incorrect positioning/placing down

Personal injury and damage to property!

- ▷ Position the pump set vertically with the motor on top.
- ▷ Use appropriate means to secure the pump set against tilting and tipping over.
- ▷ Refer to the weights given in the data sheet/on the name plate.




Fig. 29: Removing the bellmouth

- ✓ The pump has been placed in a vertical position with the bellmouth on wooden supports. It has been secured against tipping over.
 - ✓ A suitable container for collecting the lubricant is on hand.
1. Undo nuts 920.01.
 2. Attach the crane hook to the bail and lift the pump set off the bellmouth with the casing wear ring.
 3. Place the pump set down in a horizontal position on wooden supports. Secure it against rolling off.




Fig. 30: Removing the impeller

4. Undo socket head cap screws 914.07 and impeller nut 922.
5. Pull impeller 230 off shaft 210.




Fig. 31: Draining the lubricant

a	Oil drain	b	Tube
---	-----------	---	------

The oil drain screw plug is located at the front of pump casing 101.

1. Remove screw plug 903.01 and joint ring 411.01.
2. Screw in a sufficiently long tube (2) with G $\frac{1}{2}$ " thread.
3. Carefully rotate the pump set until the tube points downwards.
4. Collect the lubricant in a suitable container. Slowly lift the pump a little during this process. Determine the quantity of lubricant collected and compare it with the specified lubricant quantity. ($\Rightarrow$ Section 7.4.1.3, Page 60) . If the lubricant falls short by more than 0.63 quarts [0.6 liters] compared with the specified quantity, this suggests that the mechanical seal is defective and has to be replaced. Properly dispose of the drained lubricant.
5. Remove the tube. Fit screw plug 903.01 (oil drain) and a new joint ring with liquid sealant.

7.4.1.4.2 Filling in the lubricant




Fig. 32: Filling in the lubricant

a	Filler opening The distance between the shaft and the filler opening is smaller than the distance between the shaft and the drain opening.	b	Drain opening The distance between the shaft and the drain opening is larger than the distance between the shaft and the filler opening.
---	---	---	---

Table 17: Key to the symbols and codes

Symbol	Description
	Always apply a liquid sealing agent (e.g. Hylomar SQ32M) to sealing surfaces marked with this symbol.

- ✓ The pump set has been placed in a horizontal position and protected against rolling off.
- ✓ Screw plug 903.02 and joint ring 411.02 have been removed from the filler opening.
- ✓ The drain opening is closed with screw plug 903.02 and joint ring 411.02.
 1. Screw a sufficiently long tube with G 1/2 thread into the filler opening.
 2. Fill the lubricant in through the tube until it overflows.
 3. Remove the tube. Fit screw plug 903.02 and a new joint ring 411.02. Apply a liquid sealant.



NOTE

For commissioning: If required, top up the lubricant. (⇒ Section 5.2.3, Page 24) (⇒ Section 7.4.1.4.2, Page 63)
If the lubricant falls short by more than 0.63 quarts [0.6 liters] compared with the specified quantity, this suggests that the mechanical seal is defective and has to be replaced.

7.4.2 Lubricating the rolling element bearings

The pump set is equipped with grease-lubricated, maintenance-free rolling element bearings.

7.4.2.1 Intervals

Change the grease when carrying out a general overhaul but at least every 5 years.

7.4.2.2 Grease quality

	CAUTION Mix of different grease types Damage to the pump set! ▷ Make sure to use the right type of grease. ▷ Never mix different types of grease.
---	---

The following greases can be used to lubricate the rolling element bearings:

Table 18: Lubricant characteristics

Base oil	Type	Thickener	NLGI grade (ISO 2137)	Worked penetration at 77 °F [25 °C], 0.1 mm (DIN 51818)	Drop point (ISO 2176)	Application temperature range	Viscosity (DIN 51562) [mm²/s]	
							at 104 °F [40 °C]	at 212 °F [100 °C]
Ester oil	A	Polyurea	2	265 to 295	>482 °F [>250 °C]	-40 °F to +356 °F [-40 °C to +180 °C]	100	11

The re-lubrication and maintenance intervals apply to the grease type originally used by the manufacturer:

- Type A: Klüberquiet BQH 72-102, made by Klüber Lubrication München KG (⇒ Section 7.4.2.1, Page 63)

7.4.2.3 Grease quantity

Table 19: Grease quantity

Size	Grease type	Grease quantity			
		Drive end		Pump end	
		[ounces]	[cm³]	[ounces]	[cm³]
650 - 364	Type A	1,0	30	20,3	600
650 - 365	Type A	1,0	30	20,3	600
650 - 404	Type A	1,0	30	20,3	600
650 - 405	Type A	1,0	30	20,3	600
800 - 505	Type A	1,0	30	20,3	600

7.5 Dismantling the pump set

7.5.1 General information/Safety regulations

	⚠ DANGER Improper transport Danger to life from falling parts! Damage to the pump set! ▷ Use the attachment point provided (eyebolt, lifting lug or bail) for attaching lifting accessories. ▷ Never suspend the pump set by its power cable. ▷ Never use the lifting ropes included in KSB's scope of supply for lifting loads other than the KSB product supplied. ▷ Securely attach the lifting ropes to the pump and crane.
---	---

	 DANGER Hazardous voltage Danger to life from electric shock! ▷ Observe the safety rules for electrical work. ▷ Disconnect the equipment from the power supply. ▷ Secure the equipment against unintentional start-up. ▷ Verify that the equipment is de-energized. ▷ Ground and short-circuit the medium-voltage components. ▷ Cover any adjacent components that are connected to the power supply.
	 WARNING Unqualified personnel performing work on the pump (set) Risk of personal injury! ▷ Always have repair work and maintenance work performed by specially trained, qualified personnel.
	 WARNING Hot surface Risk of personal injury! ▷ Allow the pump set to cool down to ambient temperature.
	 WARNING Improper lifting/moving of heavy assemblies or components Personal injury and damage to property! ▷ Use suitable transport devices, lifting equipment and lifting tackle to move heavy assemblies or components.
	 WARNING Excess pressure inside the pump set Risk of personal injury when opening the pump set! ▷ Be careful when opening the inner chambers. Balance the pressure.
	 WARNING Components with sharp edges Risk of cutting or shearing injuries! ▷ Always use appropriate caution for installation and dismantling work. ▷ Wear work gloves.
	 WARNING Pump set tilting or rolling off Risk of personal injury! ▷ Make sure the pump set is secured against tilting during the entire dismantling process. ▷ For dismantling the pump set in a horizontal position, secure it against rolling off.

Observe the general safety instructions and information.
For dismantling and reassembly observe the general assembly drawing.
In the event of damage you can always contact our service departments.

7.5.2 Preparing the pump set

1. De-energize the pump set and secure it against unintentional start-up.
2. Remove the pump set from the discharge tube. (⇒ Section 7.3.1, Page 55)
3. Clean the pump set. (⇒ Section 7.3.2, Page 57)
4. Drain the lubricant. (⇒ Section 7.4.1.4, Page 60) (⇒ Section 7.4.1.4.1, Page 61)
5. Drain the leakage chamber and leave it open for the duration of the disassembly.

7.5.3 Removing the bellmouth




Fig. 33: Removing the bellmouth

- ✓ The pump set has been disconnected from the power supply and secured against unintentional start-up.
 - ✓ The pump set has been placed in a vertical position with the bellmouth on wooden supports and secured against tipping over.
1. Undo nuts 920.01.
 2. Attach the crane hook to the bail and lift the pump set off bellmouth 138. Casing wear ring 502 remains in bellmouth 138.
 3. Place the pump set in a horizontal position on wooden supports and make sure it cannot roll off.

7.5.4 Removing the impeller




Fig. 34: Removing the impeller

- ✓ The pump has been placed in a horizontal position on wooden supports and is protected against rolling off.
 - ✓ The leakage has been drained.
1. Undo socket head cap screw 914.07 and impeller nut 922.
 2. Pull impeller 230 off shaft 210.
 3. Remove keys 940.02 from shaft 210.
 4. Protect the shaft thread against damage.

7.5.5 Removing the mechanical seal

7.5.5.1 Impeller-end mechanical seal




Fig. 35: Removing the impeller-end mechanical seal

- ✓ The pump set has been positioned horizontally on wooden supports. It has been secured in this position.
 - ✓ The impeller has been removed.
 - ✓ The lubricant has been drained.
1. Remove circlip 932.01 and disc 550.05.
 2. Pull mechanical seal 433.01 off the shaft.



NOTE

To protect the mechanical seal against damage when pulling it off the shaft, placing a foil (no thicker than max. 0.01 inch [0.3 mm]) around the free shaft end is recommended.

7.5.5.2 Drive-end mechanical seal




Fig. 36: Removing the drive-end mechanical seal

✓ The impeller-end mechanical seal has been removed.

1. Attach the pump set to the lifting equipment and pull it upright.
(⇒ Section 3.2, Page 12) Place the pump set on the bellmouth with pump casing 101 down.
2. Undo hexagon socket head cap screws 914.02.
3. Attach the lifting tackle to bail 571 and lift the pump set out of pump casing 101.
4. Place motor unit 80-1 including rotor 818 with the bearing assembly and bearing housing 350 on a wooden support and protect it against rolling off.
(⇒ Section 3.2, Page 12)
5. Remove circlip 932.01 and disc 550.05.
6. Carefully pull mechanical seal 433.02 and its mating ring off the shaft.

7.5.6 Dismantling the motor section

When dismantling the motor section and the electric cables make sure that the cores/terminals are clearly marked for future reassembly.

7.5.6.1 Removing the motor housing cover




Fig. 37: Removing the motor housing cover

- ✓ Suitable lifting equipment is on hand.
 - ✓ The pump set has been disconnected from the power supply. It has been securely placed on a level surface in a vertical position.
1. Attach the lifting equipment to bail 571.
 2. Undo hexagon socket head cap screws 914.03.
 3. Carefully lift off motor housing cover 812.
 4. Remove the cable ties.
 5. Lift the motor housing cover up further until the power and control cables can be disconnected.
 6. Disconnect the cores of the control cable from the corresponding connector.
 7. Disconnect the cores of the power cable from terminal board 835. Disconnect the ground conductor and the shield of shielded cables from bearing housing 350.
 8. Place motor housing cover 812 down. Secure it against rolling off.

7.5.6.2 Dismantling the cable gland with connection cable




Fig. 38: Removing the cables and cable gland

Removing the power cable

✓ The motor housing cover has been removed, placed down and secured against rolling away.

1. Remove cover plate 82-11 or 68-3.02 from bail 571. Take out the cable gland 834.01/02 needing to be replaced.
2. Disconnect the ground conductor on the inside of motor housing cover 812. If a shielded cable is used, disconnect the shield as well.
3. Undo screws 914.04 of cable gland 834.01.
4. Pull cable gland 834.01 out of the centering seat in motor housing cover 812.

Removing the sensor cable

✓ The motor housing cover has been removed, placed down and secured against rolling away.

1. Disconnect the cores of the sensor cable from plug 81-2.
2. Undo screw 914.05 of cable gland 834.02.
3. Pull cable gland 834.02 out of the centering seat in motor housing cover 812.



NOTE

Noting down the marking and length of the cable cores to facilitate fitting the replacement cable gland is recommended.

7.6 Reassembling the pump set

7.6.1 General information/Safety regulations



⚠ WARNING

Improper lifting/moving of heavy assemblies or components

Personal injury and damage to property!

- Use suitable transport devices, lifting equipment and lifting tackle to move heavy assemblies or components.

	! WARNING Components with sharp edges Risk of cutting or shearing injuries! ▷ Always use appropriate caution for installation and dismantling work. ▷ Wear work gloves.
	! WARNING Insufficient stability Risk of crushing hands and feet! ▷ During assembly/dismantling, secure the pump (set)/pump parts against tilting or tipping over.
	CAUTION Improper reassembly Damage to the pump! ▷ Reassemble the pump (set) in accordance with the general rules of sound engineering practice. ▷ Use original spare parts only.
	NOTE Apply liquid sealant to all screw plugs. Apply liquid sealant to all wetted clearances (e.g. Hylomar SQ 32M).

Sequence Always re-assemble the pump (set) in accordance with the corresponding general assembly drawing and/or exploded view.

Sealing elements Check O-rings for any damage and replace by new O-rings if required.
Never use O-rings that have been made by cutting an O-ring cord to size and gluing the ends together.

Assembly adhesives Avoid the use of assembly adhesives if possible.

Tightening torques For reassembly, tighten all screws and bolts as indicated.
In addition, secure all screwed connections closing off the flameproof enclosure with a thread-locking agent (Loctite, type 243).

7.6.2 Installing the replacement cable gland




Fig. 39: Installing the cable gland

Table 20: Key to the symbols

Symbol	Key
	Always secure screwed connections marked with this symbol with Loctite 243 .

Installing the power cable

- ✓ The motor housing cover has been removed, placed down and protected against rolling off.
- 1. Adjust the lengths of the cable cores to the original cable gland.
- 2. Attach core identifications matching the original cable gland.
- 3. Slide O-ring 412.08 onto the core ends of the power cable and into the groove of the centering seat.
- 4. Insert cable gland 834.01 with the power cable and O-ring 412.08 into the opening provided.
- 5. Fasten cable gland 834.01 with hexagon socket head cap screws 914.05. Secure the screwed connection with Loctite 243.
- 6. Fit cable terminals to the core ends of the power cable.

Installing the control cable

- ✓ The motor housing cover has been removed, placed down and protected against rolling off.
- 1. Adjust the lengths of the cable cores to the original cable gland.
- 2. Attach core identifications matching the original cable gland.
- 3. Slide O-ring 412.07 over the short core ends of the control cable and into the groove of the centering seat.
- 4. Insert cable gland 834.03 with the control cable and O-ring 412.07 into the opening provided.
- 5. Fasten cable gland 834.03 with hexagon socket head cap screws 914.04. Secure the screwed connection with Loctite 243.

7.6.3 Fitting the motor housing cover

	 DANGER
	Electrical connection work by unqualified personnel Danger of death from electric shock and explosion! ▷ Always have the electrical connections installed by an electrically qualified person. ▷ Observe regulations IEC 60364 and, for explosion-proof versions, EN 60079.




Fig. 40: Fitting the motor housing cover

a	Anti-rotation device of the bearing housing	b	Recess for anti-rotation device in the motor housing cover
---	---	---	--

Table 21: Key to the symbols

Symbol	Key
	Always secure screwed connections marked with this symbol with Loctite 243 .

- ✓ A new O-ring has been inserted into the groove of bearing housing 350.02.
1. Attach lifting tackle to bail 571, lift up motor housing cover 812 and lower it down onto bearing housing 350.02 until only a gap remains which allows work to continue.
 2. Connect the control cable to the terminal strip as indicated.
 3. Connect the power cable cores to terminal board 835 with disc 550.23, circlip 932.23 and nuts in accordance with the wiring diagram.
 4. Fasten the ground conductor (core marking green/yellow) of the power cable to bearing housing 350.02 with bolt 901.20 and spring washer 932.20.
 5. Tie the control cable and power cable together with cable ties.
 6. Slowly lower motor housing cover 812 down onto motor housing 811. Align the anti-rotation device of the bearing housing with the recess in the motor housing cover.
 7. Fasten motor housing cover 812 to motor housing 811 or motor unit 80-1 with hexagon socket head cap screws 914.03. Secure the screwed connection with Loctite 243.
Observe the tightening torque!
 8. Prepare the motor for the leak test. Undo bolts 901.26 at bail 571 to gain access to the screw plugs for the leak test.
 9. Perform a leak test.
 10. Fasten bail 571 with hexagon head bolts 901.26.
Observe the tightening torque!
 11. Insert the power cable and control cable with cable protectors 81-97 into cover plate 82-11 or 68-3.02.
 12. Fasten the cover plate to the bail.

7.6.4 Installing the mechanical seal

Observe the following to ensure trouble-free operation of the mechanical seal:

- Only remove the protective wrapping of the contact faces immediately before assembly takes place.
- Make sure the surface of the shaft is absolutely clean and undamaged.
- Immediately before installing the mechanical seal, wet the contact faces with a drop of oil.
- For easier installation of a bellows-type mechanical seal, wet the inner bellows diameter and the O-rings with soapy water (not oil).
- Prevent the O-rings from sliding into any grooves in the shaft by lining the relevant grooves with suitable means.
- To prevent any damage to the rubber bellows, place a thin foil (of approximately 0.1 to 0.3 mm thickness) around the free shaft stub.
Slip the rotating assembly over the foil into its installation position.
Then remove the foil.

7.6.4.1 Drive-end mechanical seal




Fig. 41: Installing the drive-end mechanical seal

Table 22: Key to the symbols

Symbol	Key
	Always secure screwed connections marked with this symbol with Loctite 243 .

- ✓ The pump set has been positioned horizontally on suitable wooden supports and is secured against rolling away.
- 1. Use a suitable sleeve to press the mating ring of mechanical seal 433.02 including an O-ring into the dedicated drilled seat of bearing housing 350.01.
- 2. Slide the bellows part of mechanical seal 433.02 onto the shaft until it rests against the mating ring.
- 3. Slide disc 550.05 and circlip 932.01 onto the shaft. Press the circlip in with an assembly sleeve until it is axially fastened in the shaft groove.
- 4. Screw the testing device into the leakage drain hole (X) of bearing housing 350.01 and perform a leak test.
- 5. Attach the crane hook to the bail and pull upright motor unit 80-1 including rotor 818 with bearing and bearing housing 350.01. (⇒ Section 3.2.2, Page 12)
- 6. Place the pump set on the pump casing and bellmouth. Fasten it with hexagon socket head cap screws 914.02. Secure the screwed connection with a thread-locking agent (Loctite 243).

7.6.4.1.1 Leak test during installation of the mechanical seal

Observe the following values for leak testing:

- **Test medium:** compressed air
- **Test pressure:** maximum 14.5 psi [1 bar]
- **Test period:** 5 minutes
- 1. The pressure must not drop during the test period.
If the pressure does drop, check the seals and screwed connections.
Then perform another leak test.
- 2. If the test has been successful, remove the testing device. Do not close the leakage drain hole as this will allow drainage of any water ingress.

7.6.4.2 Impeller-end mechanical seal




Fig. 42: Installing the impeller-end mechanical seal

- ✓ The pump casing has been fastened to the motor.
 - ✓ The pump set has been positioned horizontally on a wooden support. It has been secured against rolling away.
1. Use an assembly sleeve of a suitable diameter to press the mating ring of mechanical seal 433.01 together with the O-ring into the drilled recess in the pump casing.
 2. Carefully guide on the bellows part of the mechanical seal until it rests against the mating ring.
 3. Slide disc 550.05 and circlip 932.01 onto the shaft. Press the circlip in with an assembly sleeve until it is axially fastened in the shaft groove.
 4. Check the lubricant chamber for leakage.
 5. Fill the lubricant chamber with lubricant. Then close the lubricant chamber.

7.6.5 Fitting the impeller




Fig. 43: Fitting the impeller

- ✓ The pump has been positioned horizontally on a wooden support and is protected against rolling off.
 - ✓ The impeller-end mechanical seal 433.02 has been installed.
1. Insert and fit two keys 940.02 into the keyway.
 2. Coat all sides of the shaft seat and shaft thread with an assembly paste which prevents seizure of the chrome steel parts.
 3. Guide impeller 230 onto shaft 210 until it abuts against the shaft collar.
 - ⇒ This is as far as the impeller can move along the shaft. This position results in the maximum possible clearance between the bellmouth with casing wear ring and the impeller vanes.
 4. Screw impeller nut 922 onto the shaft thread.
 5. Align the holes of impeller 230 and impeller nut 922 and fasten them with hexagon socket head cap screws 914.07.

7.6.6 Fitting the bellmouth




Fig. 44: Aligning and fitting the bellmouth

a	Bail	b	Baffles in the bellmouth
---	------	---	--------------------------

Table 23: Key to the symbols

Symbol	Key
	Always secure screwed connections marked with this symbol with Loc-tite 243 .

- ✓ Bellmouth 138 has been positioned on wooden supports on a level and solid surface.
 - ✓ Suitable lifting equipment is available.
 - ✓ The pump set has been completely pre-assembled.
 - ✓ Casing wear ring 502 has been fitted in bellmouth 138.
1. Attach lifting equipment to bail 571 and carefully pull the pump set upright.
 2. Center the pump set above bellmouth 138.
N.B. Make sure that the pin of bail 571 for attaching the lifting equipment and the anti-swirl baffles in bellmouth 138 are aligned in the same direction.
 3. Slowly lower the pump set. While lowering the pump set, make sure that studs 902.01 are aligned with the drilled holes.
 4. Then lower the pump set until it sits on bellmouth 138.
 5. Fasten all studs 902.01 with corresponding nuts 920.01. Observe the tightening torque.

7.6.7 Adjusting the clearance




Fig. 45: Adjusting the clearance

Table 24: Key to the symbols

Symbol	Key
FD	Always apply a liquid sealant (e.g. Hylomar SQ32M) to sealing surfaces marked with this symbol.

- ✓ The pump set has been placed in a horizontal position on wooden supports. It has been secured against rolling off.
- ✓ The pump set has been completely assembled.
- 1. Undo hexagon socket head cap screw 914.07 and impeller nut 922.
- 2. Screw bolts and/or threaded rods into the tapped holes on the face of impeller 230 to pull the impeller forward until the impeller vanes abut the bellmouth/casing wear ring 502.
 - ⇒ This is the maximum front position of the impeller (clearance = 0 mm).
- 3. Screw on impeller nut 922 until it abuts the front face of the impeller hub.
- 4. Screw the impeller nut on further (by dimension "B") to move the impeller along the shaft until the specified clearance "A" is established.
- 5. Use a feeler gage to measure and verify the adjusted clearance between the impeller vanes and casing wear ring 502. Perform this measurement at several points spaced around the circumference.
- 6. Align two tapped holes in the impeller hub with two holes in the impeller nut.
 - ⇒ Screw the impeller nut on slightly further until the holes are aligned.
 - ⇒ If avoidable, do not loosen the nut to align the holes.
- 7. Secure the impeller nut with hexagon socket head cap screws 914.07 and a thread-locking agent. Rotate the pump rotor by hand to check the clearance. During rotation the impeller must not touch any part of the casing.

Table 25: Clearances "A" and "B"

Size Amacan S	Clearance "A"		Clearance "B"	
	[inch]	[mm]	[inch]	[mm]
650 - 364	$0,018^{+0,008}_{-0,004}$	$0,45^{+0,2}_{-0,1}$	$0,06^{+0,024}_{-0,012}$	$1,5^{+0,6}_{-0,3}$
650 - 365	$0,018^{+0,008}_{-0,004}$	$0,45^{+0,2}_{-0,1}$	$0,06^{+0,024}_{-0,012}$	$1,5^{+0,6}_{-0,3}$
650 - 404	$0,022^{+0,008}_{-0,004}$	$0,55^{+0,2}_{-0,1}$	-	-
650 - 405	$0,022^{+0,008}_{-0,004}$	$0,55^{+0,2}_{-0,1}$	$0,067^{+0,024}_{-0,012}$	$1,7^{+0,6}_{-0,3}$
800 - 505	$0,022^{+0,008}_{-0,004}$	$0,55^{+0,2}_{-0,1}$	$0,063^{+0,024}_{-0,012}$	$1,6^{+0,6}_{-0,3}$

7.6.8 Leak testing

7.6.8.1 Checking the lubricant chamber for leakage

After reassembly the mechanical seal area/lubricant chamber must be tested for leakage. The lubricant filler opening is used for leak testing.

Observe the following values for leak testing:

- **Test medium:** compressed air
- **Test pressure:** maximum 14.5 psi [1 bar]
- **Test period:** 5 minutes




Fig. 46: Screwing in the testing device

- ✓ The impeller-end mechanical seal has been installed.
- 1. Screw the testing device tightly into the G 1/2 lubricant filler opening.
- 2. Carry out the leak test with the values specified above.
The pressure must not drop during the test period.
If the pressure does drop, check the seals and screwed connections.
- 3. Repeat the leak test if required.
- 4. If the leak test has been successful, fill in the lubricant.
- 5. Close screw plug 903.01 with new joint ring 411.01 and liquid sealant.

7.6.8.2 Leak testing the motor

	CAUTION
	Screw plug leaking or missing Damage to the motor! ▷ Never start up a pump set without screw plug 903.04. ▷ Apply a thread-locking agent (Loctite 243) to screw plug 903.04.

Observe the following values for leak testing:

- **Test medium:** nitrogen
- **Test pressure:** maximum 11.6 psi [0.8 bar]
- **Test duration:** 2 minutes




Fig. 47: Checking the motor space for leakage

1. Remove screw plug 903.04 and joint ring 411.04 at the motor housing cover.
2. Screw the testing device tightly into the opening.
3. Carry out the leak test with the values specified above.
The pressure must not drop during the test period.
If the pressure does drop, check the sealing elements and screwed connections.
Repeat the leak test.
4. Remove the testing device.

	CAUTION
	Screw plug leaking or missing
	Damage to the motor!
	▷ Never start up a pump set without screw plug 903.04.

5. Apply a thread-locking agent (Loctite 243) and liquid sealant to screw plug 903.04.
6. Re-insert screw plug 903.04 with new joint ring 411.04.

Table 26: Key to the symbols

Symbol	Key
	Always secure screwed connections marked with this symbol with Loctite 243 .
	Always apply a liquid sealant (e.g. Hylomar SQ32M) to sealing surfaces marked with this symbol.

7.7 Checking the connection of power supply and motor

Once reassembly has been completed, carry out the steps described in (⇒ Section 7.2.1, Page 54) and (⇒ Section 7.3.4, Page 57) .

7.8 Tightening torques

Table 27: Tightening torques [lbf ft] depending on thread, steel grade and property class

Steel grade	-		A2, A4		A2, A4		1.4410		1.4462	
Property class	8.8		-50		-70		$R_{p0,2} \geq 530 \text{ N/mm}^2$		$R_{p0,2} \geq 450 \text{ N/mm}^2$	
Thread	Minimum	Rated value	Minimum	Rated value	Minimum	Rated value	Minimum	Rated value	Minimum	Rated value
M4	2,2	2,5	0,7	0,8	1,5	1,7	1,8	2,1	1,5	1,7
M5	4,5	5,0	1,5	1,6	3,2	3,5	3,7	4,1	3,2	3,5
M6	7,6	8,4	2,5	2,7	5,3	5,9	6,3	7,0	5,3	5,9
M8	18	21	6	7	13	14	15	17	13	14
M10	36	41	12	13	26	28	30	33	26	28
M12	62	69	21	23	43	49	52	52	43	49
M14	99	110	32	36	69	77	82	91	69	77

Steel grade	-		A2, A4		A2, A4		1.4410		1.4462	
Property class	8.8		-50		-70		$R_{p0,2} \geq 530 \text{ N/mm}^2$		$R_{p0,2} \geq 450 \text{ N/mm}^2$	
Thread	Minimum	Rated value	Minimum	Rated value	Minimum	Rated value	Minimum	Rated value	Minimum	Rated value
M16	154	171	51	56	108	120	128	142	108	120
M20	301	334	99	110	212	235	249	277	212	235
M24	519	577	170	190	365	406	430	478	365	406
M27	756	840	248	276	532	591	626	696	532	591
M30	1035	1150	339	377	727	808	857	952	727	808
M33	1393	1547	457	507	977	1088	1153	1281	977	1088
M36	1803	2004	592	657	1268	1409	1494	1660	1268	1409
M42	2879	3200	945	1050	2025	2250	2385	2649	2025	2250
M48	4337	4819	1423	1581	3050	3388	3592	3991	3050	3388

Table 28: Tightening torques [Nm] depending on thread, steel grade and property class

Steel grade	-		A2, A4		A2, A4		1.4410		1.4462	
Property class	8.8		-50		-70		$R_{p0,2} \geq 530 \text{ N/mm}^2$		$R_{p0,2} \geq 450 \text{ N/mm}^2$	
Thread	Minimum	Rated value	Minimum	Rated value	Minimum	Rated value	Minimum	Rated value	Minimum	Rated value
M4	3,0	3,4	1,0	1,1	2,1	2,4	2,5	2,8	2,1	2,4
M5	6,1	6,8	2,0	2,2	4,3	4,8	5,0	5,6	4,3	4,8
M6	10,3	11	3,4	3,7	7,2	8,0	8,5	9,5	7,2	8,0
M8	25	28	8,2	9,1	18	19	21	23	18	19
M10	49	55	16	18	35	38	41	45	35	38
M12	85	94	28	31	59	66	70	78	59	66
M14	134	149	44	49	94	105	111	124	94	105
M16	209	232	69	76	147	163	173	192	147	163
M20	408	453	134	149	287	319	338	375	287	319
M24	704	782	231	257	495	550	583	648	495	550
M27	1025	1139	36	374	721	801	849	944	721	801
M30	1403	1559	460	511	986	1096	1162	1291	986	1096
M33	1888	2098	619	688	1327	1475	1563	1737	1327	1475
M36	2445	2717	802	891	1719	1910	2025	2250	1719	1910
M42	3904	4338	1281	1423	2745	3050	3233	3592	2745	3050
M48	5880	6534	1929	2144	4135	4594	4870	5411	4135	4594



NOTE

When using adjustable torque wrenches or drivers, select a value in the indicated range between the minimum and the rated value.

7.9 Spare parts stock

7.9.1 Ordering spare parts

Always quote the following data when ordering replacement parts or spare parts:

- Order number
- Order item number
- Type series
- Size
- Year of construction
- Motor number

Refer to the name plate for all data.

Also supply the following data:

- Part No. and description
- Quantity of spare parts
- Shipping address
- Mode of dispatch (freight, mail, express freight, air freight)

7.9.2 Recommended spare parts stock for 2 years' operation to DIN 24296

Table 29: Quantity of spare parts for recommended spare parts stock

Part No.	Description	Number of pumps (including stand-by pumps)						
		2	3	4	5	6	8	10 and more
230	Impeller	1	1	1	2	2	3	30 %
320 / 321	Rolling element bearing, pump end	1	1	2	2	3	4	50 %
322	Rolling element bearing, drive end	1	1	2	2	3	4	50 %
412.05	O-ring, for discharge tube cover	2	3	4	5	6	8	100 %
433.01	Mechanical seal, pump end	2	3	4	5	6	7	90 %
433.02	Mechanical seal, drive end	2	3	4	5	6	7	90 %
502	Casing wear ring	2	2	2	3	3	4	50 %
80-1	Motor unit	-	-	-	-	1	2	30 %
818	Rotor	-	-	-	-	1	2	30 %
834	Cable gland	1	1	2	2	2	3	40 %
99-9	Set of sealing elements, motor	4	6	8	8	9	10	100 %
99-9	Set of sealing elements, hydraulic system	4	6	8	8	9	10	100 %

8 Trouble-shooting

	⚠ WARNING
	Improper remedial work Risk of personal injury! ► For any work performed in order to remedy faults observe the relevant information given in this operating manual and/or the product literature provided by the accessories manufacturers.

If problems occur that are not described in the following table, consultation with KSB Service is required.

- A** Pump is running but does not deliver
- B** Pump delivers insufficient flow rate
- C** Excessive current/power input
- D** Insufficient discharge head
- E** Vibrations and noise during pump operation

Table 30: Trouble-shooting

A	B	C	D	E	Possible cause	Remedy ⁴⁾
-	X	-	-	X	Water level dropping excessively during operation	Check supply and capacity of system (sump floor area). Check level control equipment.
X	X	-	-	X	Total pressure corresponding to $NPSH_{\text{Pump}}$ too high Total pressure corresponding to $NPSH_{\text{System}}$ too low	Increase fluid level on the suction side. Clean screening equipment if required.
X	X	X	-	X	Penetration of air into the pump due to formation of an air pocket - Suction-side water level too low	Increase the suction-side water level. If this is not possible or unsuccessful, please contact KSB.
X	X	X	-	X	Unfavorable flow to the pump inlet	Improve the flow to the intake chamber (contact KSB).
-	X	X	-	X	Pump running in off-design conditions - part load / overload	Check the pump's operating data.
X	X	-	X	X	Pump clogged by deposits	Clean intake and pump components.
-	X	X	X	X	Wear	Replace worn components by new ones.
-	X	-	X	X	Impermissible air or gas content in the fluid handled	Contact KSB.
-	-	-	-	X	System-induced vibrations	Contact KSB.
-	-	X	-	X	Wrong direction of rotation	Check the electrical connection of motor and control system (if any).
X	-	-	-	-	No voltage	Check the electrical installation. Contact the energy supplier.
X	-	-	-	-	Motor winding or electric cable are defective.	Replace with original KSB cable, or contact KSB.
-	-	X	-	X	Worn or defective rolling element bearings	Contact KSB.
X	-	-	-	-	The thermistor tripping unit with manual reset for temperature limiter has tripped the pump as a result of the permissible winding temperature being exceeded.	Have cause determined and eliminated by qualified and trained personnel.
X	-	-	-	-	Motor has been tripped by leakage monitor.	Have cause determined and eliminated by qualified and trained personnel.

⁴ The pump pressure must be released before attempting to remedy faults on parts which are subjected to pressure. Disconnect the pump set from the power supply!

A	B	C	D	E	Possible cause	Remedy ⁴⁾
X	-	-	-	-	Mechanical seal monitor has tripped.	Have cause determined and eliminated by qualified and trained personnel.
X	-	-	-	-	Bearing temperature monitor has tripped.	Have cause determined and eliminated by qualified and trained personnel.

9 Related Documents

9.1 General assembly drawing of pump sets with UAG motors (DKA motor)




Fig. 48: General assembly drawing

Table 31: Detailed views





 920.25 550.25 68-3.02 81-97.01 81-97.02 59-7.01 550.25 901.25	 932.01 550.05 433.01 433.02
Detailed view: bracket	Detailed view: mechanical seal
 914.19 901.20 932.20 99-17 FK KB 836.02	 970.02 970.01 Y X 970.04 970.05 970.03 970.01 - factory name plate 970.02 - name plate 970.03 - oil drain 970.04 - oil filler plug 970.05 - leakage drain
Detailed view: connection space	Pump signage
	Always secure screwed connections marked with this symbol with Loctite 243 .
	Always apply a liquid sealant (e.g. Hylomar SQ32M) to sealing surfaces marked with this symbol.
	Use a lubricant paste (e.g. Altemp Q NB 50).

Table 32: List of components

Part No.	Description	Part No.	Description
101	Pump casing	758	Screen
138	Bellmouth	80-1	Motor unit
230	Impeller	81-45	Float switch
320	Angular contact ball bearing	81-56	Motor moisture protection device
321	Deep groove ball bearing	81-97.01/.02	Cable protector
322	Cylindrical roller bearing	812	Motor housing cover
350.01/.02	Bearing housing	818	Rotor

Part No.	Description	Part No.	Description
360	Bearing cover	834.01/.03	Cable gland
411.01/.02/.04/.26	Joint ring	835	Terminal board
412.01/.02/.03/.05/.07/.08	O-ring	836.01/.02	Terminal strip
421.01/.02	Lip seal	885	Chain
433.01/.02/.03	Mechanical seal	99-17	Desiccant
59-7.01	Support	901.20/.25/.26	Hexagon head bolt
500.01/.02	Ring	902.01	Stud
502	Casing wear ring	903.01/.02/.04	Screw plug
520.01	Sleeve	914.01/.02/.03/.04/.05/.07/.19	Hexagon socket head cap screw
550.05/.25	Disc	920.01/.25	Nut
563	Bolt	922	Impeller nut
571	Bail	932.01/.02/.03/.04/.20	Circlip
68-3.02	Cover plate	940.02	Key
69-6.01	Temperature sensor	970.01/.02/.03/.04/.05	Label/plate

9.2 Cable bundle




Fig. 49: Cable bundle

1)	Basic design
2)	Design with lifting lug
3)	Design with support

*) : Only required for galvanized version

	NOTE
	Dimension M = 2 inches [50 mm]

Table 33: Key to the symbols

Symbol	Key
	Always secure screwed connections marked with this symbol with Loc-tite 243 .




Fig. 50: Section A - A, position of power cable, control cable and rope

c	Power cable	d	Control cable
---	-------------	---	---------------

Table 34: List of components of the cable bundle

Part number	Description	Part number	Description
59-7	Support	59-47	Lifting lug
59-8	Turnbuckle	719.05	Flexible tube
59-17.01/02	Shackle	720	Spacer
59-24	Rope / support rope	733.05	Cable clamp

9.3 Wiring diagrams

9.3.1 Wiring diagram




Fig. 51: Wiring diagram

* Shielded cable option

¹⁾ Up to 6 parallel cable pairs possible

9.3.2 Wiring diagrams for the sensors

Standard
pump sets




Fig. 52: Wiring diagram for sensors of standard pump sets

*	Shielded cables option
Ⓐ	Motor temperature (PTC)
Ⓑ	Mechanical seal leakage
Ⓒ	Bearing temperature (lower bearing assembly)
Ⓓ	Bearing temperature (upper bearing assembly)
Ⓕ	Leakage inside the motor

Pump sets
with additional Pt100
motor temperature
monitoring




Fig. 53: Sensor wiring diagram for pump sets with additional Pt100 motor temperature monitoring

Ⓐ	Motor temperature (PTC)
Ⓑ	Mechanical seal leakage
Ⓒ	Bearing temperature (lower bearing assembly)
Ⓓ	Bearing temperature (upper bearing assembly)
Ⓕ	Leakage inside the motor
Ⓖ	Motor temperature (Pt100)

9.4 Dimensions

9.4.1 UAG motors (650-364 to 800-505) [inch]




Fig. 54: Pump set dimensions

Table 35: Pump set dimensions [inch]

Size	Motor size	Number of poles	h ₁	h ₂	h ₃	h ₄	l ₁	l ₂	d ₁	d ₂	d ₃	d ₄	d ₅	[lbs] ⁵⁾
650 - 364	26	6	82 1/4	80 3/4	10 1/4	63 1/4	25 5/8	2 3/4	24 5/8	19 11/16	20 1/16	15 3/8	1 3/8	2050
650 - 364	30	6	82 1/4	80 3/4	10 1/4	63 1/4	25 5/8	2 3/4	24 5/8	19 11/16	20 1/16	15 3/8	1 3/8	2072
650 - 364	50	6	82 1/4	80 3/4	10 1/4	63 1/4	25 5/8	2 3/4	24 5/8	19 11/16	20 1/16	15 3/8	1 3/8	2094
650 - 365	30	6	82 1/4	80 3/4	10 1/4	63 1/4	25 5/8	2 3/4	24 5/8	19 11/16	20 1/16	15 3/8	1 3/8	2039
650 - 365	50	6	82 1/4	80 3/4	10 1/4	63 1/4	25 5/8	2 3/4	24 5/8	19 11/16	20 1/16	15 3/8	1 3/8	2072
650 - 365	65	6	82 1/4	80 3/4	10 1/4	63 1/4	25 5/8	2 3/4	24 5/8	19 11/16	20 1/16	15 3/8	1 3/8	2138
650 - 404	30	6	82 7/8	81	11 3/8	63 3/4	26 1/8	2 3/4	24 7/16	21 1/4	19 11/16	15 3/8	1 3/8	2094
650 - 404	50	6	82 7/8	81	11 3/8	63 3/4	26 1/8	2 3/4	24 7/16	21 1/4	19 11/16	15 3/8	1 3/8	2116
650 - 404	65	6	82 7/8	81	11 3/8	63 3/4	26 1/8	2 3/4	24 7/16	21 1/4	19 11/16	15 3/8	1 3/8	2183
650 - 405	50	6	82 7/8	81	11 3/8	63 3/4	26 1/8	2 3/4	24 7/16	21 1/4	19 11/16	15 3/8	1 3/8	2072
650 - 405	65	6	82 7/8	81	11 3/8	63 3/4	26 1/8	2 3/4	24 7/16	21 1/4	19 11/16	15 3/8	1 3/8	2138
650 - 405	80	6	90 3/4	88 7/8	11 3/8	71 5/8	26 1/8	2 3/4	24 7/16	21 1/4	19 11/16	15 3/8	1 3/8	2425
650 - 405	100	6	90 3/4	88 7/8	11 3/8	71 5/8	26 1/8	2 3/4	24 7/16	21 1/4	19 11/16	15 3/8	1 3/8	2535
650 - 405	120	6	90 3/4	88 7/8	11 3/8	71 5/8	26 1/8	2 3/4	24 7/16	21 1/4	19 11/16	15 3/8	1 3/8	2673
800 - 505	75	8	94 1/2	92 2/8	14 5/8	75 3/8	31 1/4	3 1/2	30 1/2	26 3/16	25 1/4	18 3/4	1 3/4	3395
800 - 505	100	8	99 1/4	97	14 5/8	80 1/8	31 1/4	3 1/2	30 1/2	26 3/16	25 1/4	18 3/4	1 3/4	3660
800 - 505	120	8	99 1/4	97	14 5/8	80 1/8	31 1/4	3 1/2	30 1/2	26 3/16	25 1/4	18 3/4	1 3/4	3770

⁵⁾ Pump set complete with 32.8 ft [10 m] power cable (460 V) and 16.4 ft [5 m] support rope




Fig. 55: Discharge tube dimensions

A	Suction umbrella; option for reducing the minimum water level
1)	This dimension depends on the type of installation, see booklet of general arrangement drawings.

Table 36: Discharge tube dimensions [inch]

Size	Motor size	Number of poles	D	d ₇	h ₇	d ₉	s ₁
650 - 364	26	6	26	20 ⁷ / ₈	8 ⁷ / ₈	35 ⁷ / ₁₆	⁵ / ₁₆
650 - 364	30	6	26	20 ⁷ / ₈	8 ⁷ / ₈	35 ⁷ / ₁₆	⁵ / ₁₆
650 - 364	50	6	26	20 ⁷ / ₈	8 ⁷ / ₈	35 ⁷ / ₁₆	⁵ / ₁₆
650 - 365	30	6	26	20 ⁷ / ₈	8 ⁷ / ₈	35 ⁷ / ₁₆	⁵ / ₁₆
650 - 365	50	6	26	20 ⁷ / ₈	8 ⁷ / ₈	35 ⁷ / ₁₆	⁵ / ₁₆
650 - 365	65	6	26	20 ⁷ / ₈	8 ⁷ / ₈	35 ⁷ / ₁₆	⁵ / ₁₆
650 - 404	30	6	26	20 ⁷ / ₈	10 ⁷ / ₁₆	35 ⁷ / ₁₆	⁵ / ₁₆
650 - 404	50	6	26	20 ⁷ / ₈	10 ⁷ / ₁₆	35 ⁷ / ₁₆	⁵ / ₁₆
650 - 404	65	6	26	20 ⁷ / ₈	10 ⁷ / ₁₆	35 ⁷ / ₁₆	⁵ / ₁₆
650 - 405	50	6	26	20 ⁷ / ₈	10 ⁷ / ₁₆	35 ⁷ / ₁₆	⁵ / ₁₆
650 - 405	65	6	26	20 ⁷ / ₈	10 ⁷ / ₁₆	35 ⁷ / ₁₆	⁵ / ₁₆
650 - 405	80	6	26	20 ⁷ / ₈	10 ⁷ / ₁₆	35 ⁷ / ₁₆	⁵ / ₁₆
650 - 405	100	6	26	20 ⁷ / ₈	10 ⁷ / ₁₆	35 ⁷ / ₁₆	⁵ / ₁₆
650 - 405	120	6	26	20 ⁷ / ₈	10 ⁷ / ₁₆	35 ⁷ / ₁₆	⁵ / ₁₆
800 - 505	75	8	32	26 ³ / ₄	13 ³ / ₁₆	41 ³ / ₈	⁵ / ₁₆
800 - 505	100	8	32	26 ³ / ₄	13 ³ / ₁₆	41 ³ / ₈	⁵ / ₁₆
800 - 505	120	8	32	26 ³ / ₄	13 ³ / ₁₆	41 ³ / ₈	⁵ / ₁₆

9.4.2 UAG motors (650-364 to 800-505) [mm]




Fig. 56: Dimensions of the pump set

Table 37: Dimensions of the pump set [mm]

Size	Motor size	Num-ber of poles	h_1	h_2	h_3	h_4	l_1	l_2	d_1	d_2	d_3	d_4	d_5	[kg] ⁶⁾
650 - 364	26	6	2090	2042	260	1605	651	70	625	500	510	390	35	940
650 - 364	30	6	2090	2042	260	1605	651	70	625	500	510	390	35	940
650 - 364	50	6	2090	2042	260	1605	651	70	625	500	510	390	35	950
650 - 365	30	6	2090	2042	260	1605	651	70	625	500	510	390	35	930
650 - 365	50	6	2090	2042	260	1605	651	70	625	500	510	390	35	940
650 - 365	65	6	2090	2058	260	1605	651	70	625	500	510	390	35	970
650 - 404	30	6	2105	2058	290	1620	665	70	620	–	500	390	35	950
650 - 404	50	6	2105	2058	290	1620	665	70	620	–	500	390	35	960
650 - 404	65	6	2105	2058	290	1620	665	70	620	–	500	390	35	990
650 - 405	50	6	2105	2058	290	1620	665	70	620	–	500	390	35	940
650 - 405	65	6	2105	2258	290	1620	665	70	620	–	500	390	35	970
650 - 405	80	6	2305	2258	290	1820	665	70	620	–	500	390	35	1100
650 - 405	100	6	2305	2258	290	1820	665	70	620	–	500	390	35	1150
650 - 405	120	6	2305	2343	290	1820	665	70	620	–	500	390	35	1190
800 - 505	75	8	2400	2463	370	1915	795	90	775	665	645	480	45	1540
800 - 505	100	8	2520	2463	370	2035	795	90	775	665	645	480	45	1660
800 - 505	120	8	2520	2463	370	2035	795	90	775	665	645	480	45	1710

⁶⁾ Complete pump set with 32.8 ft [10 m] power cable (460 V) and 16.4 ft [5 m] support rope




Fig. 57: Dimensions of the discharge tube

A	Suction umbrella; option for reducing the minimum water level
1)	This dimension depends on the type of installation, see booklet of general arrangement drawings.

Table 38: Dimensions of the discharge tube [mm]

Size	Motor size	Number of poles	D	d ₇	h ₇	d ₉	s ₁
650 - 364	26	6	660	530	225	900	7,1
650 - 364	30	6	660	530	225	900	7,1
650 - 364	50	6	660	530	225	900	7,1
650 - 365	30	6	660	530	225	900	7,1
650 - 365	50	6	660	530	225	900	7,1
650 - 365	65	6	660	530	225	900	7,1
650 - 404	30	6	660	530	265	900	7,1
650 - 404	50	6	660	530	265	900	7,1
650 - 404	65	6	660	530	265	900	7,1
650 - 405	50	6	660	530	265	900	7,1
650 - 405	65	6	660	530	265	900	7,1
650 - 405	80	6	660	530	265	900	7,1
650 - 405	100	6	660	530	265	900	7,1
650 - 405	120	6	660	530	265	900	7,1
800 - 505	75	8	813	680	335	1050	8
800 - 505	100	8	813	680	335	1050	8
800 - 505	120	8	813	680	335	1050	8

9.5 General arrangement drawings

9.5.1 General arrangement drawings [inch]

9.5.1.1 Installation type BU (Amacan S 650-364 to 800-505)




Table 39: Dimensions [inch]

Size	D	b	b ₁		b ₂		d ₇	d ₈	d ₉	d ₁₂
			Suction umbrella		Suction umbrella					
			✗	✓	✗	✓				
			d ₈	d ₉	d ₈	d ₉				
650-364	26	39 ³ / ₈	7 ⁷ / ₈	—	7 ⁷ / ₈	—	20 ⁷ / ₈	26	35 ⁷ / ₁₆	27 ⁹ / ₁₆
650-365	26	39 ³ / ₈	7 ⁷ / ₈	—	7 ⁷ / ₈	—	20 ⁷ / ₈	26	35 ⁷ / ₁₆	27 ⁹ / ₁₆
650-404	26	39 ³ / ₈	7 ⁷ / ₈	—	7 ⁷ / ₈	—	20 ⁷ / ₈	26	35 ⁷ / ₁₆	27 ⁹ / ₁₆

⁷ All dimensions for foundation recesses apply to discharge tube design without intermediate flange.

Size	D	b	b ₁		b ₂		d ₇	d ₈	d ₉	d ₁₂
			Suction umbrella		Suction umbrella					
			✗	✓	✗	✓				
			d ₈	d ₉	d ₈	d ₉				
650-405	26	49 ³ / ₁₆	9 ¹³ / ₁₆	—	9 ¹³ / ₁₆	—	20 ⁷ / ₈	26	35 ⁷ / ₁₆	27 ⁹ / ₁₆
800-505	32	49 ³ / ₁₆	9 ¹³ / ₁₆	—	9 ¹³ / ₁₆	—	26 ³ / ₄	31 ⁷ / ₈	41 ⁵ / ₁₆	33 ⁷ / ₁₆

Table 40: Dimensions [inch]

Size	e ₁ ⁸⁾		h ₇	l _{min.}	m	p ₁	p ₂	t ₃ ⁸⁾	t _{4 min.} ⁹⁾
	Suction umbrella								
	✗	✓							
	d ₈	d ₉							
650-364	16 ⁹ / ₁₆	21 ¹ / ₄	8 ⁷ / ₈	22 ¹³ / ₁₆	29 ¹ / ₂	33 ⁷ / ₁₆	23 ¹ / ₄	10 ¹ / ₄	92 ¹ / ₂
650-365	16 ⁹ / ₁₆	21 ¹ / ₄	8 ⁷ / ₈	22 ¹³ / ₁₆	29 ¹ / ₂	33 ⁷ / ₁₆	23 ¹ / ₄	10 ¹ / ₄	92 ¹ / ₂
650-404	16 ⁹ / ₁₆	21 ¹ / ₄	10 ⁷ / ₁₆	22 ¹³ / ₁₆	29 ¹ / ₂	33 ⁷ / ₁₆	23 ¹ / ₄	10 ¹ / ₄	100 ¹³ / ₁₆
650-405	16 ⁹ / ₁₆	21 ¹ / ₄	10 ⁷ / ₁₆	32 ¹¹ / ₁₆	29 ¹ / ₂	33 ⁷ / ₁₆	23 ¹ / ₄	12 ⁵ / ₈	107 ¹ / ₁₆
800-505	19 ¹¹ / ₁₆	24 ⁷ / ₁₆	13 ³ / ₁₆	29 ¹ / ₂	35 ¹³ / ₁₆	39 ³ / ₈	29 ¹ / ₈	12 ⁵ / ₈	104 ³ / ₄

t₂ = 1.1 × water level, maximum 2 × t₁ (depending on head H and structure)

Height of corner lining (b₁ and b₂) like t₂

Permissible tolerances:

- Tolerances in building construction to DIN 18202, Part 4, Group B
- Welded design: B/F to DIN EN ISO 13920
- Tolerances for conical seat (detail Y): ISO 2768-mH

Table 41: Loss diagram





Illustration of the overflow head Loss diagram

h₀

Calculation formulas:

$$H = H_{\text{geo}} + \Delta H_v$$

⁸ Observe this dimension.

⁹ Value for maximum motor length

ΔH_v


- Overflow head h_0 (see diagram)
- Loss in the riser (pipe friction)
- Outlet loss $v^2 / 2g$ (v refers to D_a)

Overflow head h_0 depends on Q and the discharge diameter $\varnothing D_A$. The characteristic curve values only apply to unimpeded outlet in all directions; otherwise they are approximate values only.

Diagram for minimum water level t_1

Open chamber

t_1 [inch]






Minimum water level


d_8 = design: without suction umbrella (standard)

d_9 = design: with suction umbrella

9.5.1.2 Installation type BG



Detail X:
Support plate of the discharge tube
Drawing: without pump



Detail Y:
Seating ring

- ① Minimum water level (see diagram on the following page),
- ② Approach flow,
- ③ Flow-straightening vane (⇒ Section 9.5.1.7, Page 115)

Table 42: Dimensions [inch]

Size	D	b	b ₁	b ₂	d ₇	d ₈	d ₁₀	d ₁₂	e ₁ ¹¹⁾
800-535	32	59 1/16	11 13/16	23 5/8	28 3/8	33 1/16	34 13/16	33 7/16	17 11/16
850-550	34 3/16	59 1/16	11 13/16	23 5/8	29 1/8	33 1/16	34 13/16	36 1/4	17 11/16
900-600	36	59 1/16	11 13/16	23 5/8	31 1/2	32 5/16	33 7/8	38 3/16	17 11/16
900-615	36	70 7/8	14 3/16	28 3/8	30 11/16	35 13/16	37 5/8	38 3/16	20 1/2
900-620	36	49 3/16	9 13/16	19 11/16	30 5/16	31 1/8	32 11/16	38 3/16	16 5/16
1000-655	40	70 7/8	14 3/16	28 3/8	36 1/4	39 3/8	40 15/16	42 1/8	20 1/2
1300-820	51 15/16	90 9/16	18 1/8	36 1/4	42 1/2	51 3/16	53 9/16	54 5/16	26 3/4

¹⁰ All dimensions for foundation recesses apply to discharge tube design without intermediate flange.

¹¹ Observe this dimension.

Table 43: Dimensions [inch]

Size	e ₂	h ₇	l _{min}	m	p ₁	p ₂	t ₃ ¹²⁾	t _{4 min} ¹³⁾	t ₉
800-535	29 1/2	12 13/16	59 1/16	35 3/16	39 3/8	29 1/8	14 15/16	110 1/4	22 7/16
850-550	29 1/2	14 3/4	59 1/16	38 9/16	41 5/16	31 1/8	14 15/16	127 15/16	22 7/16
900-600	29 1/2	16 5/16	59 1/16	41 5/16	44 1/8	33 7/8	14 15/16	126	22 7/16
900-615	35 7/16	16 9/16	70 7/8	41 5/16	44 1/8	33 7/8	17 5/16	126	26
900-620	24 5/8	14 3/8	49 3/16	41 5/16	44 1/8	33 7/8	12 5/8	126	18 1/2
1000-655	35 7/16	20 1/4	70 7/8	45 1/4	48 1/16	37 13/16	17 5/16	147 5/8	26
1300-820	45 1/4	21 7/16	90 9/16	57 1/2	59 13/16	49 5/8	22 1/16	153 9/16	33 7/16

t₂ = 1.1 × water level, maximum 2 × t₁ (depending on head H and structure)

Height of corner lining (b₁ and b₂) like t₂

Permissible tolerances:

- Tolerances in building construction to DIN 18202, Part 4, Group B
- Welded design: B/F to DIN EN ISO 13920
- Tolerances for conical seat (detail Y): ISO 2768-mH

Loss diagram





Illustration of the overflow head Loss diagram

h₀

Calculation formulas:

$$H = H_{\text{geo}} + \Delta H_v$$

Δ H_v

- Overflow head h₀ (see diagram)
- Loss in the riser (pipe friction)
- Outlet loss v² / 2 g (v refers to D_A)

Overflow head h₀ depends on Q and the discharge diameter Ø D_A. The characteristic curve values only apply to unimpeded outlet in all directions; otherwise they are approximate values only.


¹² Observe this dimension.

¹³ Value for maximum motor length

Diagram for minimum water level t_1


Covered intake chamber

t_1 [inch]




Minimum water level

9.5.1.3 Installation type CG (Amacan S 650-364 to 800-505)





0 - 90°
v_{max} = 3.3 ft/sec.




Foundation recesses ¹⁴⁾

A - A



Detail X:

Support plate of the discharge tube
Drawing: without pump



Detail Y:

Seating ring

- ① Vent line,
- ② Minimum water level (see diagram on the next page),
- ③ Approach flow,
- ④ Flow-straightening vane (⇒ Section 9.5.1.7, Page 115) ,
- ⑤ Connect the discharge line to the discharge tube without transmitting any stresses and strains.

¹⁴⁾ All dimensions for foundation recesses apply to discharge tube design without intermediate flange.

Table 44: Dimensions [inch]

Size	D	DN ₂ min	DN ₂ max	a	a ₁ ¹⁵⁾	a ₂ ¹⁵⁾	a ₃ ¹⁵⁾	b	b ₁	b ₂	d ₇	d ₈	d ₁₀
650-364	26	15 ³ / ₄	23 ⁵ / ₈	24	41 ⁵ / ₁₆	31 ¹ / ₂	15 ¹⁵ / ₁₆	39 ³ / ₈	7 ⁷ / ₈	15 ³ / ₄	20 ⁷ / ₈	21 ⁵ / ₈	23 ⁵ / ₈
650-365	26	15 ³ / ₄	23 ⁵ / ₈	24	41 ⁵ / ₁₆	31 ¹ / ₂	15 ¹⁵ / ₁₆	39 ³ / ₈	7 ⁷ / ₈	15 ³ / ₄	20 ⁷ / ₈	21 ⁵ / ₈	23 ⁵ / ₈
650-404	26	15 ³ / ₄	23 ⁵ / ₈	24	41 ⁵ / ₁₆	31 ¹ / ₂	15 ¹⁵ / ₁₆	39 ³ / ₈	7 ⁷ / ₈	15 ³ / ₄	20 ⁷ / ₈	21 ⁵ / ₈	23 ⁵ / ₈
650-405	26	15 ³ / ₄	23 ⁵ / ₈	24	41 ⁵ / ₁₆	31 ¹ / ₂	15 ¹⁵ / ₁₆	49 ³ / ₁₆	9 ¹³ / ₁₆	19 ¹¹ / ₁₆	20 ⁷ / ₈	26	27 ³ / ₁₆
800-505	32	19 ¹¹ / ₁₆	31 ¹ / ₂	27 ⁹ / ₁₆	48 ¹ / ₁₆	38 ³ / ₁₆	18 ⁷ / ₈	49 ³ / ₁₆	9 ¹³ / ₁₆	19 ¹¹ / ₁₆	26 ³ / ₄	27 ⁹ / ₁₆	28 ¹⁵ / ₁₆


Table 45: Dimensions [inch]

Size	e ₁ ¹⁶⁾	e ₂	h ₇	l _{min}	m ¹⁵⁾	m ₁ ¹⁵⁾	n ¹⁵⁾	p ₁ ¹⁵⁾	p ₂ ¹⁵⁾	t ₃ ¹⁶⁾	t ₄ min ¹⁷⁾	t ₅ min ¹⁵⁾	t ₉
650-364	11 ¹³ / ₁₆	19 ¹¹ / ₁₆	8 ⁷ / ₈	39 ³ / ₈	43 ⁵ / ₁₆	16 ¹⁵ / ₁₆	45 ¹¹ / ₁₆	33 ⁷ / ₈	37 ¹³ / ₁₆	10 ¹ / ₄	92 ¹ / ₂	28 ³ / ₈	14 ³ / ₄
650-365	11 ¹³ / ₁₆	19 ¹¹ / ₁₆	8 ⁷ / ₈	39 ³ / ₈	43 ⁵ / ₁₆	16 ¹⁵ / ₁₆	45 ¹¹ / ₁₆	33 ⁷ / ₈	37 ¹³ / ₁₆	10 ¹ / ₄	92 ¹ / ₂	28 ³ / ₈	14 ³ / ₄
650-404	11 ¹³ / ₁₆	19 ¹¹ / ₁₆	10 ⁷ / ₁₆	39 ³ / ₈	43 ⁵ / ₁₆	16 ¹⁵ / ₁₆	45 ¹¹ / ₁₆	33 ⁷ / ₈	37 ¹³ / ₁₆	10 ¹ / ₄	102 ³ / ₈	28 ³ / ₈	14 ³ / ₄
650-405	14 ³ / ₄	24 ⁵ / ₈	10 ⁷ / ₁₆	49 ³ / ₁₆	43 ⁵ / ₁₆	16 ¹⁵ / ₁₆	45 ¹¹ / ₁₆	33 ⁷ / ₈	37 ¹³ / ₁₆	12 ⁵ / ₈	108 ¹ / ₄	28 ³ / ₈	18 ¹ / ₂
800-505	14 ³ / ₄	24 ⁵ / ₈	13 ³ / ₁₆	49 ³ / ₁₆	50	19 ⁷ / ₈	54 ¹ / ₈	42 ⁵ / ₁₆	46 ¹ / ₄	12 ⁵ / ₈	106 ⁵ / ₁₆	32 ⁷ / ₈	18 ¹ / ₂

Permissible tolerances:

- Tolerances in building construction to DIN 18202, Part 4, Group B
- Welded design: B/F to DIN EN ISO 13920
- Tolerances for conical seat (detail Y): ISO 2768-mH
- Discharge flanges to DIN EN 1092-1 PN6, DIN EN 1092-2 PN6

Loss diagram



- ① - DN₂ = 7 ⁷/₈ inches
- ② - DN₂ = 9 ¹³/₁₆ inches
- ③ - DN₂ = 11 ¹³/₁₆ inches
- ④ - DN₂ = 13 ³/₄ inches
- ⑤ - DN₂ = 15 ³/₄ inches
- ⑥ - DN₂ = 19 ¹¹/₁₆ inches

- ⑦ - DN₂ = 23 ⁵/₈ inches
- ⑧ - DN₂ = 27 ⁹/₁₆ inches
- ⑨ - DN₂ = 31 ¹/₂ inches
- ⑩ - DN₂ = 35 ⁷/₁₆ inches
- ⑪ - DN₂ = 39 ³/₈ inches
- ⑫ - DN₂ = 43 ⁵/₁₆ inches

- ⑬ - DN₂ = 47 ¹/₄ inches
- ⑭ - DN₂ = 51 ³/₁₆ inches
- ⑮ - DN₂ = 55 ¹/₈ inches
- ⑯ - DN₂ = 59 ¹/₁₆ inches
- ⑰ - DN₂ = 63 inches

Calculation formulas:

¹⁵⁾ Selected for DN₂max

¹⁶⁾ Observe this dimension.

¹⁷⁾ Value for maximum motor length

$$H = H_{\text{geo}} + \Delta H_v$$

$$\Delta H_v$$

- Loss in the riser (pipe friction)
- $H_{v \text{ ges.}}$ (see diagram)


$H_{v \text{ ges.}}$ comprises:

- Elbow
- Discharge line length = 5
× DN₂
- Swing check valve
- Outlet losses $v^2 / 2 g$

Diagram for minimum water level t_1



Covered intake chamber

t_1 [inch]





Minimum water level

9.5.1.4 Installation type CU (Amacan S 650-364 to 800-505)




Foundation recesses ¹⁸⁾

A - A



Detail X:

Support plate of the discharge tube
Drawing: without pump



Detail Y:

Seating ring

- ① Vent line,
- ② Minimum water level (see diagram on the next page),
- ③ Approach flow,
- ④ Flow-straightening vane (⇒ Section 9.5.1.7, Page 115) ,
- ⑤ Connect the discharge line to the discharge tube without transmitting any stresses and strains.

¹⁸⁾ All dimensions for foundation recesses apply to discharge tube design without intermediate flange.

Table 46: Dimensions [inch]

Size	D	DN ₂ min	DN ₂ max	a	a ₁ ¹⁹⁾	a ₂ ¹⁹⁾	a ₃ ¹⁹⁾	b	b ₁		b ₂		d ₇
									Suction umbrella		Suction umbrella		
									✗	✓	✗	✓	
									d ₈	d ₉	d ₈	d ₉	
650-364	26	15 ¾	23 ⅝ ₈	24	41 ⅝ ₁₆	31 ½	15 ⅝ ₁₆	39 ⅜	7 ⅞	—	7 ⅞	—	20 ⅞
650-365	26	15 ¾	23 ⅝ ₈	24	41 ⅝ ₁₆	31 ½	15 ⅝ ₁₆	39 ⅜	7 ⅞	—	7 ⅞	—	20 ⅞
650-404	26	15 ¾	23 ⅝ ₈	24	41 ⅝ ₁₆	31 ½	15 ⅝ ₁₆	39 ⅜	7 ⅞	—	7 ⅞	—	20 ⅞
650-405	26	15 ¾	23 ⅝ ₈	24	41 ⅝ ₁₆	31 ½	15 ⅝ ₁₆	49 ⅜ ₁₆	9 ⅜ ₁₆	—	9 ⅜ ₁₆	—	20 ⅞
800-505	32	19 ⅜ ₁₆	31 ½	27 ⅞ ₁₆	48 ⅜ ₁₆	38 ⅜ ₁₆	18 ⅞	49 ⅜ ₁₆	9 ⅜ ₁₆	—	9 ⅜ ₁₆	—	26 ¾

Table 47: Dimensions [inch]

Size	d ₈	d ₉	e ₁ ²⁰⁾		h ₇	l _{min}	m ¹⁹⁾	m ₁ ¹⁹⁾	n ¹⁹⁾	p ₁ ¹⁹⁾	p ₂ ¹⁹⁾	t ₃ ²⁰⁾	t _{4 min} ²¹⁾	t _{5 min} ¹⁹⁾
			Suction um- brella											
			✗	✓										
			d ₈	d ₉										
650-364	26	35 ⁷ / ₁₆	16 ⁹ / ₁₆	21 ¹ / ₄	8 ⁷ / ₈	22 ¹³ / ₁₆	43 ⁵ / ₁₆	16 ¹⁵ / ₁₆	45 ¹¹ / ₁₆	33 ⁷ / ₈	37 ¹³ / ₁₆	10 ¹ / ₄	92 ½	28 ³ / ₈
650-365	26	35 ⁷ / ₁₆	16 ⁹ / ₁₆	21 ¹ / ₄	8 ⁷ / ₈	22 ¹³ / ₁₆	43 ⁵ / ₁₆	16 ¹⁵ / ₁₆	45 ¹¹ / ₁₆	33 ⁷ / ₈	37 ¹³ / ₁₆	10 ¹ / ₄	92 ½	28 ³ / ₈
650-404	26	35 ⁷ / ₁₆	16 ⁹ / ₁₆	21 ¹ / ₄	10 ⁷ / ₁₆	22 ¹³ / ₁₆	43 ⁵ / ₁₆	16 ¹⁵ / ₁₆	45 ¹¹ / ₁₆	33 ⁷ / ₈	37 ¹³ / ₁₆	10 ¹ / ₄	102 ³ / ₈	28 ³ / ₈
650-405	26	35 ⁷ / ₁₆	16 ⁹ / ₁₆	21 ¹ / ₄	10 ⁷ / ₁₆	32 ¹¹ / ₁₆	43 ⁵ / ₁₆	16 ¹⁵ / ₁₆	45 ¹¹ / ₁₆	33 ⁷ / ₈	37 ¹³ / ₁₆	12 ⁵ / ₈	108 ¹ / ₄	28 ³ / ₈
800-505	31 ⁷ / ₈	41 ⁵ / ₁₆	16 ¹¹ / ₁₆	24 ⁷ / ₁₆	13 ³ / ₁₆	29 ¹ / ₂	50	19 ⁷ / ₈	54 ¹ / ₈	42 ⁵ / ₁₆	46 ¹ / ₄	12 ⁵ / ₈	106 ⁵ / ₁₆	32 ⁷ / ₈

t₂ = 1.1 × water level, maximum 2 × t₁ (depending on head H and structure)

Height of corner lining (b₁ and b₂) like t₂

Permissible tolerances:


- Tolerances in building construction to DIN 18202, Part 4, Group B
- Welded design: B/F to DIN EN ISO 13920
- Tolerances for conical seat (detail Y): ISO 2768-mH
- Discharge flanges to DIN EN 1092-1 PN6, DIN EN 1092-2 PN6

¹⁹ Selected for DN2max

²⁰ Observe this dimension.

²¹ Value for maximum motor length

Loss diagram



- | | | |
|--------------------------------------|-------------------------------------|-------------------------------------|
| ① - $DN_2 = 7 \frac{7}{8}$ inches | ⑦ - $DN_2 = 23 \frac{5}{8}$ inches | ⑬ - $DN_2 = 47 \frac{1}{4}$ inches |
| ② - $DN_2 = 9 \frac{13}{16}$ inches | ⑧ - $DN_2 = 27 \frac{9}{16}$ inches | ⑭ - $DN_2 = 51 \frac{3}{16}$ inches |
| ③ - $DN_2 = 11 \frac{13}{16}$ inches | ⑨ - $DN_2 = 31 \frac{1}{2}$ inches | ⑮ - $DN_2 = 55 \frac{1}{8}$ inches |
| ④ - $DN_2 = 13 \frac{3}{4}$ inches | ⑩ - $DN_2 = 35 \frac{7}{16}$ inches | ⑯ - $DN_2 = 59 \frac{1}{16}$ inches |
| ⑤ - $DN_2 = 15 \frac{3}{4}$ inches | ⑪ - $DN_2 = 39 \frac{3}{8}$ inches | ⑰ - $DN_2 = 63$ inches |
| ⑥ - $DN_2 = 19 \frac{11}{16}$ inches | ⑫ - $DN_2 = 43 \frac{5}{16}$ inches | |

Calculation formulas:

$$H = H_{\text{geo}} + \Delta H_v$$

ΔH_v


- Loss in the riser (pipe friction)
- $H_{v \text{ ges.}}$ (see diagram)

$H_{v \text{ ges.}}$ comprises:

- Elbow
- Discharge line length = 5
× DN_2
- Swing check valve
- Outlet losses $v^2 / 2 g$

Diagram for minimum water level t_1

Open chamber





Minimum water level

d_8 = design: without suction umbrella (standard)



d_9 = design: with suction umbrella

9.5.1.5 Installation type DG (Amacan S 650-364 to 800-505)




Foundation recesses ²²⁾

A - A



Detail X:

Support plate of the discharge tube
Drawing: without pump



Detail Y:

Seating ring

- ① Vent line,
- ② Minimum water level (see diagram on the next page),
- ③ Approach flow,
- ④ Flow-straightening vane (⇒ Section 9.5.1.7, Page 115) ,
- ⑤ Not pressure-proof,
- ⑥ Connect the discharge line to the discharge tube without transmitting any stresses and strains.

²²⁾ All dimensions for foundation recesses apply to discharge tube design without intermediate flange.

Table 48: Dimensions [inch]

Size	D	DN ₂ min	DN ₂ max	a	a ₁	a ₂	b	b ₁	b ₂	d ₇	d ₈	d ₁₀
650-364	26	15 ³ / ₄	23 ⁵ / ₈	24	31 ⁷ / ₈	22 ¹ / ₁₆	39 ³ / ₈	7 ⁷ / ₈	15 ³ / ₄	20 ⁷ / ₈	21 ⁵ / ₈	23 ⁵ / ₈
650-365	26	15 ³ / ₄	23 ⁵ / ₈	24	31 ⁷ / ₈	22 ¹ / ₁₆	39 ³ / ₈	7 ⁷ / ₈	15 ³ / ₄	20 ⁷ / ₈	21 ⁵ / ₈	23 ⁵ / ₈
650-404	26	15 ³ / ₄	23 ⁵ / ₈	24	31 ⁷ / ₈	22 ¹ / ₁₆	39 ³ / ₈	7 ⁷ / ₈	15 ³ / ₄	20 ⁷ / ₈	21 ⁵ / ₈	23 ⁵ / ₈
650-405	26	15 ³ / ₄	23 ⁵ / ₈	24	31 ⁷ / ₈	22 ¹ / ₁₆	49 ³ / ₁₆	9 ¹³ / ₁₆	19 ¹¹ / ₁₆	20 ⁷ / ₈	26	26
800-505	32	19 ¹¹ / ₁₆	31 ¹ / ₂	27 ⁹ / ₁₆	37 ¹³ / ₁₆	27 ¹⁵ / ₁₆	49 ³ / ₁₆	9 ¹³ / ₁₆	19 ¹¹ / ₁₆	26 ³ / ₄	27 ⁹ / ₁₆	27 ⁹ / ₁₆


Table 49: Dimensions [inch]

Size	e ₁ ²³⁾	e ₂	h ₇	l _{min}	m	n	p ₁	p ₂	t ₃ ²³⁾	t ₄ min ²⁴⁾	t ₉
650-364	11 ¹³ / ₁₆	19 ¹¹ / ₁₆	8 ⁷ / ₈	39 ³ / ₈	33 ⁷ / ₈	43 ¹¹ / ₁₆	31 ⁷ / ₈	35 ¹³ / ₁₆	10 ¹ / ₄	92 ¹ / ₂	14 ³ / ₄
650-365	11 ¹³ / ₁₆	19 ¹¹ / ₁₆	8 ⁷ / ₈	39 ³ / ₈	33 ⁷ / ₈	43 ¹¹ / ₁₆	31 ⁷ / ₈	35 ¹³ / ₁₆	10 ¹ / ₄	92 ¹ / ₂	14 ³ / ₄
650-404	11 ¹³ / ₁₆	19 ¹¹ / ₁₆	10 ⁷ / ₁₆	39 ³ / ₈	33 ⁷ / ₈	43 ¹¹ / ₁₆	31 ⁷ / ₈	35 ¹³ / ₁₆	10 ¹ / ₄	102 ³ / ₈	14 ³ / ₄
650-405	14 ³ / ₄	24 ⁵ / ₈	10 ⁷ / ₁₆	49 ³ / ₁₆	33 ⁷ / ₈	43 ¹¹ / ₁₆	31 ⁷ / ₈	35 ¹³ / ₁₆	12 ⁵ / ₈	108 ¹ / ₄	18 ¹ / ₂
800-505	14 ³ / ₄	24 ⁵ / ₈	13 ³ / ₁₆	49 ³ / ₁₆	40 ⁹ / ₁₆	49 ⁵ / ₈	37 ¹³ / ₁₆	41 ³ / ₄	12 ⁵ / ₈	106 ⁵ / ₁₆	18 ¹ / ₂

Permissible tolerances:

- Tolerances in building construction to DIN 18202, Part 4, Group B
- Welded design: B/F to DIN EN ISO 13920
- Tolerances for conical seat (detail Y): ISO 2768-mH
- Discharge flanges to DIN EN 1092-1 PN6, DIN EN 1092-2 PN6

Loss diagram



- ① - DN₂ = 7 ⁷/₈ inches
 ② - DN₂ = 9 ¹³/₁₆ inches
 ③ - DN₂ = 11 ¹³/₁₆ inches
 ④ - DN₂ = 13 ³/₄ inches
 ⑤ - DN₂ = 15 ³/₄ inches
 ⑥ - DN₂ = 19 ¹¹/₁₆ inches

- ⑦ - DN₂ = 23 ⁵/₈ inches
 ⑧ - DN₂ = 27 ⁹/₁₆ inches
 ⑨ - DN₂ = 31 ¹/₂ inches
 ⑩ - DN₂ = 35 ⁷/₁₆ inches
 ⑪ - DN₂ = 39 ³/₈ inches
 ⑫ - DN₂ = 43 ⁵/₁₆ inches

- ⑬ - DN₂ = 47 ¹/₄ inches
 ⑭ - DN₂ = 51 ³/₁₆ inches
 ⑮ - DN₂ = 55 ¹/₈ inches
 ⑯ - DN₂ = 59 ¹/₁₆ inches
 ⑰ - DN₂ = 63 inches

Calculation formulas:

$$H = H_{\text{geo}} + \Delta H_v$$

²³ Observe this dimension.

²⁴ Value for maximum motor length

ΔH_V


- Loss in the elbow $h_{V\ Kr}$ (see diagram)
- Loss in the riser (pipe friction)
- $H_{V\ System}$ (valves, etc.)

H Determine V_{System} for the specific system.

Diagram for minimum water level t_1


Covered intake chamber

t_1 [inch]



Minimum water level

9.5.1.6 Example of installation type DU (Amacan S 650 - 364 to 800 - 505)



- ① Vent line,
- ② Minimum water level (see diagram on the next page),
- ③ Approach flow,
- ④ Flow-straightening vane (⇒ Section 9.5.1.7, Page 115) ,
- ⑤ Not pressure-proof,
- ⑥ Connect the discharge line to the discharge tube without transmitting any stresses and strains.

²⁵ All dimensions for foundation recesses apply to discharge tube design without intermediate flange.

Table 50: Dimensions [inch]

Size	D	DN ₂ min	DN ₂ max	a	a ₁	a ₂	b	b ₁		b ₂		d ₇
								Suction umbrella		Suction umbrella		
								✗	✓	✗	✓	
								d ₈	d ₉	d ₈	d ₉	
650-364	26	15 ¾	23 ⅝	24	31 ⅞	22 ⅛	39 ⅜	7 ⅞	–	7 ⅞	–	20 ⅞
650-365	26	15 ¾	23 ⅝	24	31 ⅞	22 ⅛	39 ⅜	7 ⅞	–	7 ⅞	–	20 ⅞
650-404	26	15 ¾	23 ⅝	24	31 ⅞	22 ⅛	39 ⅜	7 ⅞	–	7 ⅞	–	20 ⅞
650-405	26	15 ¾	23 ⅝	24	31 ⅞	22 ⅛	49 ⅜	9 ⅜	–	9 ⅜	–	20 ⅞
800-505	32	19 ⅞	31 ½	27 ⅞	37 ⅜	27 ⅝	49 ⅜	9 ⅜	–	9 ⅜	–	26 ¾

Table 51: Dimensions [inch]

Size	d ₈	d ₉	e ₁ ²⁶⁾		h ₇	l _{min}	m	n	p ₁	p ₂	t ₃ ²⁶⁾	t _{4 min} ²⁷⁾
			Suction umbrella									
			✗	✓								
			d ₈	d ₉								
650-364	26	35 ⁷ / ₁₆	16 ⁹ / ₁₆	21 ¹ / ₄	8 ⁷ / ₈	22 ¹³ / ₁₆	33 ⁷ / ₈	43 ¹¹ / ₁₆	31 ⁷ / ₈	35 ¹³ / ₁₆	10 ¹ / ₄	92 ¹ / ₂
650-365	26	35 ⁷ / ₁₆	16 ⁹ / ₁₆	21 ¹ / ₄	8 ⁷ / ₈	22 ¹³ / ₁₆	33 ⁷ / ₈	43 ¹¹ / ₁₆	31 ⁷ / ₈	35 ¹³ / ₁₆	10 ¹ / ₄	92 ¹ / ₂
650-404	26	35 ⁷ / ₁₆	16 ⁹ / ₁₆	21 ¹ / ₄	10 ⁷ / ₁₆	22 ¹³ / ₁₆	33 ⁷ / ₈	43 ¹¹ / ₁₆	31 ⁷ / ₈	35 ¹³ / ₁₆	10 ¹ / ₄	102 ³ / ₈
650-405	26	35 ⁷ / ₁₆	16 ⁹ / ₁₆	21 ¹ / ₄	10 ⁷ / ₁₆	22 ¹³ / ₁₆	33 ⁷ / ₈	43 ¹¹ / ₁₆	31 ⁷ / ₈	35 ¹³ / ₁₆	10 ⁵ / ₈	108 ¹ / ₄
800-505	31 ⁷ / ₈	41 ⁵ / ₁₆	19 ¹¹ / ₁₆	24 ⁷ / ₁₆	13 ³ / ₁₆	29 ¹ / ₂	40 ⁹ / ₁₆	49 ⁵ / ₈	37 ¹³ / ₁₆	41 ³ / ₄	10 ⁵ / ₈	106 ⁵ / ₁₆

t₂ = 1.1 × water level, maximum 2 × t₁ (depending on head H and structure)
Height of corner lining (b₁ and b₂) like t₂


Permissible tolerances:

- Tolerances in building construction to DIN 18202, Part 4, Group B
- Welded design: B/F to DIN EN ISO 13920
- Tolerances for conical seat (detail Y): ISO 2768-mH
- Discharge flanges to DIN EN 1092-1 PN6, DIN EN 1092-2 PN6

²⁶⁾ Observe this dimension.

²⁷⁾ Value for maximum motor length

Loss diagram



- | | | |
|--------------------------------------|-------------------------------------|-------------------------------------|
| ① - $DN_2 = 7 \frac{7}{8}$ inches | ⑦ - $DN_2 = 23 \frac{5}{8}$ inches | ⑬ - $DN_2 = 47 \frac{1}{4}$ inches |
| ② - $DN_2 = 9 \frac{13}{16}$ inches | ⑧ - $DN_2 = 27 \frac{9}{16}$ inches | ⑭ - $DN_2 = 51 \frac{3}{16}$ inches |
| ③ - $DN_2 = 11 \frac{13}{16}$ inches | ⑨ - $DN_2 = 31 \frac{1}{2}$ inches | ⑮ - $DN_2 = 55 \frac{1}{8}$ inches |
| ④ - $DN_2 = 13 \frac{3}{4}$ inches | ⑩ - $DN_2 = 35 \frac{7}{16}$ inches | ⑯ - $DN_2 = 59 \frac{1}{16}$ inches |
| ⑤ - $DN_2 = 15 \frac{3}{4}$ inches | ⑪ - $DN_2 = 39 \frac{3}{8}$ inches | ⑰ - $DN_2 = 63$ inches |
| ⑥ - $DN_2 = 19 \frac{11}{16}$ inches | ⑫ - $DN_2 = 43 \frac{5}{16}$ inches | |

Calculation formulas:

$$H = H_{geo} + \Delta H_v$$


$$\Delta H_v$$

- Loss in the elbow $h_{V Kr}$ (see diagram)
- Loss in the riser (pipe friction)
- $H_{V System}$ (valves, etc.)

Determine $H_{V System}$ for the specific system.

Diagram for minimum water level t_1

Open chamber



Minimum water level

d_8 = design: without suction umbrella (standard)

d_9 = design: with suction umbrella


9.5.1.7 Dimensions of the flow-straightening vane

Design of the intake chamber wall surfaces (to prevent vortex formation)

The flow-straightening vane is indispensable for the inlet conditions of the pump set. The flow-straightening vane prevents the development of a submerged vortex (floor vortex) which could cause a drop in performance, for example. In addition, the floor and wall surfaces of the intake chamber should be designed as a rough concrete surface. Rough surfaces minimize the separation of boundary layers that may cause wall vortices and floor vortices.

Flow-straightening vane and intake chamber


- The anti-swirl baffles in the bellmouth must be aligned with the flow-straightening vane.
- The bail of the pump is oriented in the same direction as the anti-swirl baffles in the bellmouth.




Installation position of the pump set

1	Bail	2	Anti-swirl baffles
3	Flow-straightening vane		

Variant 1
Flow-straightening vane cast from concrete



Variant 2
Steel section



A	Bolted to the floor of the intake chamber	C	Discharge tube
B	Flow-straightening vane centered beneath the discharge tube	D	Intake chamber

Dimensions for installation types BU, CU, DU

Table 52: Dimensions [inch]

Size	h_R	s_R	s_1	s_2	$(e_1)^{28)}$		$I_R^{29)}$	
					Suction umbrella		Suction umbrella	
					$\times$	$\checkmark$	$\times$	$\checkmark$
					d_8	d_9	d_8	d_9
650-364	$5 \frac{7}{8}$	$\frac{3}{8}$	$\frac{13}{16}$	$2 \frac{3}{8}$	$16 \frac{9}{16}$	$21 \frac{1}{4}$	$32 \frac{7}{8}$	$37 \frac{5}{8}$
650-365	$5 \frac{7}{8}$	$\frac{3}{8}$	$\frac{13}{16}$	$2 \frac{3}{8}$	$16 \frac{9}{16}$	$21 \frac{1}{4}$	$32 \frac{7}{8}$	$37 \frac{5}{8}$
650-404	$5 \frac{7}{8}$	$\frac{3}{8}$	$\frac{13}{16}$	$2 \frac{3}{8}$	$16 \frac{9}{16}$	$21 \frac{1}{4}$	$32 \frac{7}{8}$	$37 \frac{5}{8}$
650-405	$7 \frac{1}{2}$	$\frac{3}{8}$	$\frac{13}{16}$	$2 \frac{3}{4}$	$16 \frac{9}{16}$	$21 \frac{1}{4}$	$34 \frac{7}{16}$	$41 \frac{5}{16}$
800-505	$7 \frac{1}{2}$	$\frac{3}{8}$	$\frac{13}{16}$	$2 \frac{3}{4}$	$19 \frac{11}{16}$	$24 \frac{7}{16}$	$41 \frac{5}{16}$	$45 \frac{1}{4}$
800-535	$9 \frac{1}{16}$	$\frac{3}{8}$	1	$3 \frac{9}{16}$	$19 \frac{11}{16}$	$29 \frac{1}{2}$	$43 \frac{5}{16}$	$53 \frac{1}{8}$
850-550	$9 \frac{1}{16}$	$\frac{3}{8}$	1	$3 \frac{9}{16}$	$20 \frac{11}{16}$	$29 \frac{1}{2}$	$43 \frac{5}{16}$	$53 \frac{1}{8}$
900-600	$9 \frac{1}{16}$	$\frac{3}{8}$	1	$3 \frac{9}{16}$	$21 \frac{5}{8}$	$29 \frac{1}{2}$	$47 \frac{1}{4}$	$59 \frac{1}{16}$
900-615	$10 \frac{7}{16}$	$\frac{1}{2}$	1	$3 \frac{15}{16}$	$21 \frac{5}{8}$	$29 \frac{1}{2}$	$51 \frac{3}{16}$	$59 \frac{1}{16}$
900-620	$7 \frac{1}{2}$	$\frac{3}{8}$	$\frac{13}{16}$	$2 \frac{3}{4}$	$21 \frac{5}{8}$	$24 \frac{7}{16}$	$41 \frac{5}{16}$	$45 \frac{1}{4}$
1000-655	$10 \frac{7}{16}$	$\frac{1}{2}$	1	$3 \frac{15}{16}$	$23 \frac{5}{8}$	$33 \frac{7}{16}$	$51 \frac{3}{16}$	$59 \frac{1}{16}$
1300-820	$13 \frac{3}{16}$	$\frac{1}{2}$	$1 \frac{3}{16}$	$4 \frac{3}{4}$	$29 \frac{1}{2}$	$39 \frac{3}{8}$	64	$73 \frac{13}{16}$

Installation types BG, CG, DG




Fig. 58: Flow-straightening vane for covered intake chamber

Table 53: Dimensions [inch]


Size	h_R	s_R	s_1	s_2
650-364	$5 \frac{7}{8}$	$\frac{3}{8}$	$\frac{13}{16}$	$2 \frac{3}{8}$
650-365	$5 \frac{7}{8}$	$\frac{3}{8}$	$\frac{13}{16}$	$2 \frac{3}{8}$
650-404	$5 \frac{7}{8}$	$\frac{3}{8}$	$\frac{13}{16}$	$2 \frac{3}{8}$
650-405	$7 \frac{1}{2}$	$\frac{3}{8}$	$\frac{13}{16}$	$2 \frac{3}{4}$
800-505	$7 \frac{1}{2}$	$\frac{3}{8}$	$\frac{13}{16}$	$2 \frac{3}{4}$
800-535	$9 \frac{1}{16}$	$\frac{3}{8}$	1	$3 \frac{9}{16}$
850-550	$9 \frac{1}{16}$	$\frac{3}{8}$	1	$3 \frac{9}{16}$
900-600	$9 \frac{1}{16}$	$\frac{3}{8}$	1	$3 \frac{9}{16}$
900-615	$10 \frac{7}{16}$	$\frac{1}{2}$	1	$3 \frac{15}{16}$
900-620	$7 \frac{1}{2}$	$\frac{3}{8}$	$\frac{13}{16}$	$2 \frac{3}{4}$
1000-655	$10 \frac{7}{16}$	$\frac{1}{2}$	1	$3 \frac{15}{16}$
1300-820	$13 \frac{3}{16}$	$\frac{1}{2}$	$1 \frac{3}{16}$	$4 \frac{3}{4}$

²⁸ See installation examples for types BU, CU and DU

²⁹ Adjust length I_R of the flow straightening vane to the 45° angle of the intake chamber.

9.5.2 General arrangement drawings [mm]

9.5.2.1 Installation type BU



- ①: Minimum water level (values see diagram on the next page),
 ②: Approach flow,
 ③: Flow-straightening vane ($\Rightarrow$ Section 9.5.2.7, Page 136)

Table 54: Dimensions [mm]

Size	D	b	b ₁		b ₂		d ₇	d ₈	d ₉	d ₁₂
			Suction umbrella		Suction umbrella					
			✗	✓	✗	✓				
			d ₈	d ₉	d ₈	d ₉				
650-364	660	1000	200	—	200	—	530	660	900	700
650-365	660	1000	200	—	200	—	530	660	900	700
650-404	660	1000	200	—	200	—	530	660	900	700
650-405	660	1250	250	—	250	—	530	660	900	700
800-505	813	1250	250	—	250	—	680	810	1050	850

³⁰⁾ All dimensions for foundation recesses apply to discharge tube design without intermediate flange.

Table 55: Dimensions [mm]

Size	e ₁ ³¹⁾		h ₇	l _{min.}	m	p ₁	p ₂	t ₃ ³¹⁾	t _{4 min.} ³²⁾
	Suction umbrella								
	✗	✓							
	d ₈	d ₉							
650-364	420	540	225	580	750	850	590	260	2350
650-365	420	540	225	580	750	850	590	260	2350
650-404	420	540	265	580	750	850	590	260	2560
650-405	420	540	265	830	750	850	590	320	2720
800-505	500	620	335	750	910	1000	740	320	2660

$t_2 = 1.1 \times \text{water level, maximum } 2 \times t_1$ (depending on head H and structure)
Height of corner lining (b_1 and b_2) like t_2

Permissible tolerances:

- Tolerances in building construction to DIN 18202, Part 4, Group B
- Welded design: B/F to DIN EN ISO 13920
- Tolerances for conical seat (detail Y): ISO 2768-mH





Illustration of the overflow head h_u



Loss diagram

Calculation formulas:

$$H = H_{geo} + \Delta H_v$$

$$\Delta H_v$$

- Overflow head h_u (see diagram)
- Loss in the riser (pipe friction)
- Outlet loss $v^2 / 2g$ (v refers to D_A)

Overflow head h_u depends on Q and the discharge design $\varnothing D_A$. The characteristic curve values only apply to unimpeded outlet in all directions; otherwise they are approximate values only.


³¹ Observe this dimension.

³² Value for maximum motor length

Minimum water level diagram

Open chamber

t_1 [mm]






Minimum water level


d_8 = design: **without** suction umbrella (standard)

d_9 = design: **with** suction umbrella

9.5.2.2 Installation type BG



Detail X:
Support plate of the discharge tube
Drawing: without pump



Detail Y:
Seating ring

- ①: Minimum water level (values see diagram on the next page),
②: Approach flow, $v_{\max} = 1 \text{ m/s}$
③: Flow-straightening vane ($\Rightarrow$ Section 9.5.2.7, Page 136)

Table 56: Dimensions [mm]

Size	D	b	b ₁	b ₂	d ₇	d ₈	d ₁₀	d ₁₂	e ₁ ³⁴⁾
650-364	660	1000	200	400	530	550	600	700	300
650-365	660	1000	200	400	530	550	600	700	300
650-404	660	1000	200	400	530	550	600	700	300
650-405	660	1250	250	500	530	660	690	700	375
800-505	813	1250	250	500	680	700	735	850	375

³³ All dimensions for foundation recesses apply to discharge tube design without intermediate flange.

³⁴ Observe this dimension.

Table 57: Dimensions [mm]

Size	e ₂	h ₇	l _{min}	m	p ₁	p ₂	t ₃ ³⁴⁾	t _{4 min} ³⁵⁾	t ₉
650-364	500	225	1000	750	850	590	260	2350	375
650-365	500	225	1000	750	850	590	260	2350	375
650-404	500	265	1000	750	850	590	260	2560	375
650-405	625	265	1250	750	850	590	320	2720	470
800-505	625	335	1250	910	1000	740	320	2660	470

Permissible tolerances:

- Tolerances in building construction to DIN 18202, Part 4, Group B
- Welded design: B/F to DIN EN ISO 13920
- Tolerances for conical seat (detail Y): ISO 2768-mH





Illustration of the overflow head
h₀



Loss diagram

Calculation formulas:

$$H = H_{\text{geo}} + \Delta H_v$$

$$\Delta H_v$$


- Overflow head h₀ (see diagram)
- Loss in the riser (pipe friction)
- Outlet loss $v^2 / 2g$ (v refers to D_A)

Overflow head h₀ depends on Q and the discharge design Ø D_A. The characteristic curve values only apply to unimpeded outlet in all directions; otherwise they are approximate values only.

³⁵ Value for maximum motor length





Minimum water level diagram

Covered intake chamber




Minimum water level

9.5.2.3 Installation type CU



Detail X:
Support plate of the discharge tube
Drawing: without pump



Detail Y:
Seating ring

- ①: Vent line,
- ②: Minimum water level (values see diagram on the next page),
- ③: Approach flow,
- ④: Flow-straightening vane (⇒ Section 9.5.2.7, Page 136)
- ⑤: Connect the discharge line to the discharge tube without transmitting any stresses or strains.

³⁶ All dimensions for foundation recesses apply to discharge tube design without intermediate flange.

Table 58: Dimensions [mm]

Size	D	DN ₂ min	DN ₂ max	a	a ₁ ³⁷⁾	a ₂ ³⁷⁾	a ₃ ³⁷⁾	b	b ₁		b ₂		d ₇
									Suction um- brella		Suction um- brella		
									✗	✓	✗	✓	
									d ₈	d ₉	d ₈	d ₉	
650-364	660	400	600	610	1050	800	405	1000	200	–	200	–	530
650-365	660	400	600	610	1050	800	405	1000	200	–	200	–	530
650-404	660	400	600	610	1050	800	405	1000	200	–	200	–	530
650-405	660	400	600	610	1050	800	405	1250	250	–	250	–	530
800-505	813	500	800	700	1220	970	480	1250	250	–	250	–	680

Table 59: Dimensions [mm]

Size	d ₈	d ₉	e ₁ ³⁸⁾		h ₇	l _{min}	m ³⁹⁾	m ₁ ³⁹⁾	n ³⁹⁾	p ₁ ³⁹⁾	p ₂ ³⁹⁾	t ₃ ³⁸⁾	t _{4 min} ⁴⁰⁾	t ₅ ³⁹⁾
			Suction umbrella											
			✗	✓										
			d ₈	d ₉										
650-364	660	900	420	540	225	580	1100	430	1160	860	960	260	2350	720
650-365	660	900	420	540	225	580	1100	430	1160	860	960	260	2350	720
650-404	660	900	420	540	265	580	1100	430	1160	860	960	260	2600	720
650-405	660	900	420	540	265	830	1100	430	1160	860	960	320	2750	720
800-505	810	1050	500	620	335	750	1270	505	1375	1075	1175	320	2700	835

t₂ = 1.1 × water level, maximum 2 × t₁ (depending on head H and structure)

Height of corner lining (b₁ and b₂) like t₂

Permissible tolerances:

- Tolerances in building construction to DIN 18202, Part 4, Group B
- Welded design: B/F to DIN EN ISO 13920
- Tolerances for conical seat (detail Y): ISO 2768-mH
- Discharge flanges to DIN EN 1092-1 PN6, DIN EN 1092-2 PN6


³⁷⁾ Designed for DN₂max.

³⁸⁾ Observe this dimension.

³⁹⁾ Selected for DN₂max

⁴⁰⁾ Value for maximum motor length

Loss diagram



- ① - $DN_2 = 200$ mm
- ② - $DN_2 = 250$ mm
- ③ - $DN_2 = 300$ mm
- ④ - $DN_2 = 350$ mm
- ⑤ - $DN_2 = 400$ mm
- ⑥ - $DN_2 = 500$ mm
- ⑦ - $DN_2 = 600$ mm
- ⑧ - $DN_2 = 700$ mm
- ⑨ - $DN_2 = 800$ mm
- ⑩ - $DN_2 = 900$ mm
- ⑪ - $DN_2 = 1000$ mm
- ⑫ - $DN_2 = 1100$ mm
- ⑬ - $DN_2 = 1200$ mm
- ⑭ - $DN_2 = 1300$ mm
- ⑮ - $DN_2 = 1400$ mm
- ⑯ - $DN_2 = 1500$ mm
- ⑰ - $DN_2 = 1600$ mm

Calculation formulas:

$$H = H_{\text{geo}} + \Delta H_v$$

ΔH_v

- Loss in the riser (pipe friction)
- $H_{v\text{ ges.}}$ (see diagram)


$H_{v\text{ ges.}}$ comprises:

- Elbow
- Discharge pipe length = $5 \times DN_2$
- Swing check valve
- Outlet losses $v^2/2g$

Minimum water level diagram

Open chamber

t_i [mm]






Minimum water level


d_8 = design: **without** suction umbrella (standard)

d_9 = design: **with** suction umbrella

9.5.2.4 Installation type CG



Detail X:
Support plate of the discharge tube
Drawing: without pump



Detail Y:
Seating ring

- ①: Vent line,
- ②: Minimum water level (values see diagram on the next page),
- ③: Approach flow,
- ④: Flow-straightening vane (⇒ Section 9.5.2.7, Page 136)
- ⑤: Connect the discharge line to the discharge tube without transmitting any stresses or strains.

⁴¹ All dimensions for foundation recesses apply to discharge tube design without intermediate flange.

Table 60: Dimensions [mm]


Size	D	DN ₂ min	DN ₂ max	a	a ₁ ⁴²⁾	a ₂ ⁴²⁾	a ₃ ⁴²⁾	b	b ₁	b ₂	d ₇	d ₈	d ₁₀
650-364	660	400	600	610	1050	800	405	1000	200	400	530	550	600
650-365	660	400	600	610	1050	800	405	1000	200	400	530	550	600
650-404	660	400	600	610	1050	800	405	1000	200	400	530	550	600
650-405	660	400	600	610	1050	800	405	1250	250	500	530	660	690
800-505	813	500	800	700	1220	970	480	1250	250	500	680	700	735

Table 61: Dimensions [mm]

Size	e ₁ ⁴³⁾	e ₂	h ₇	l _{min}	m ⁴²⁾	m ₁ ⁴²⁾	n ⁴²⁾	p ₁ ⁴²⁾	p ₂ ⁴²⁾	t ₃ ⁴³⁾	t _{4min} ⁴⁴⁾	t _{5min} ⁴²⁾	t ₉
650-364	300	500	225	1000	1100	430	1160	860	960	260	2350	720	375
650-365	300	500	225	1000	1100	430	1160	860	960	260	2350	720	375
650-404	300	500	265	1000	1100	430	1160	860	960	260	2600	720	375
650-405	375	625	265	1250	1100	430	1160	860	960	320	2750	720	470
800-505	375	625	335	1250	1270	505	1375	1075	1175	320	2700	835	470

Permissible tolerances:

- Tolerances in building construction to DIN 18202, Part 4, Group B
- Welded design: B/F to DIN EN ISO 13920
- Tolerances for conical seat (detail Y): ISO 2768-mH
- Discharge flanges to DIN EN 1092-1 PN6, DIN EN 1092-2 PN6

Loss diagram


- ① - DN₂ = 200 mm
- ② - DN₂ = 250 mm
- ③ - DN₂ = 300 mm
- ④ - DN₂ = 350 mm
- ⑤ - DN₂ = 400 mm
- ⑥ - DN₂ = 500 mm
- ⑦ - DN₂ = 600 mm
- ⑧ - DN₂ = 700 mm
- ⑨ - DN₂ = 800 mm
- ⑩ - DN₂ = 900 mm
- ⑪ - DN₂ = 1000 mm
- ⑫ - DN₂ = 1100 mm
- ⑬ - DN₂ = 1200 mm
- ⑭ - DN₂ = 1300 mm
- ⑮ - DN₂ = 1400 mm
- ⑯ - DN₂ = 1500 mm
- ⑰ - DN₂ = 1600 mm

Calculation formulas:

$$H = H_{\text{geo}} + \Delta H_v$$

$$\Delta H_v$$

- Loss in the riser (pipe friction)
- $H_{v \text{ ges.}}$ (see diagram)

$H_{v \text{ ges.}}$ comprises:

- Elbow
- Discharge pipe length = 5 x DN₂
- Swing check valve
- Outlet losses $v^2/2g$


⁴²⁾ Designed for DN₂max.

⁴³⁾ Observe this dimension.

⁴⁴⁾ Value for maximum motor length


Minimum water level diagram

Covered intake chamber



Minimum water level

9.5.2.5 Installation type DU



- ① Vent line,
- ② Minimum water level (see diagram on the next page),
- ③ Approach flow,
- ④ Flow-straightening vane (⇒ Section 9.5.2.7, Page 136),
- ⑤: Not pressure-proof,
- ⑥: Connect the discharge line to the discharge tube without transmitting any stresses or strains.

⁴⁵ All dimensions for foundation recesses apply to discharge tube design without intermediate flange.

Table 62: Dimensions [mm]

Size	D	DN ₂ min	DN ₂ max	a	a ₁	a ₂	b	b ₁		b ₂		d ₇
								Suction umbrella		Suction umbrella		
								✗	✓	✗	✓	
								d ₈	d ₉	d ₈	d ₉	
650-364	660	400	600	610	810	560	1000	200	–	200	–	530
650-365	660	400	600	610	810	560	1000	200	–	200	–	530
650-404	660	400	600	610	810	560	1000	200	–	200	–	530
650-405	660	400	600	610	810	560	1250	250	–	250	–	530
800-505	813	500	800	700	960	710	1250	250	–	250	–	680

Table 63: Dimensions [mm]

Size	d ₈	d ₉	e ₁ ⁴⁶⁾		h ₇	l _{min}	m	n	p ₁	p ₂	t ₃ ⁴⁶⁾	t _{4 min} ⁴⁷⁾
			Suction umbrella									
			✗	✓								
			d ₈	d ₉								
650-364	660	900	420	540	225	580	860	1110	810	910	260	2350
650-365	660	900	420	540	225	580	860	1110	810	910	260	2350
650-404	660	900	420	540	265	580	860	1110	810	910	260	2600
650-405	660	900	420	540	265	830	860	1110	810	910	320	2750
800-505	810	1050	500	620	335	750	1030	1260	960	1060	320	2700

t₂ = 1.1 × water level, maximum 2 × t₁ (depending on head H and structure)


Height of corner lining (b₁ and b₂) like t₂

Permissible tolerances:

- Tolerances in building construction to DIN 18202, Part 4, Group B
- Welded design: B/F to DIN EN ISO 13920
- Tolerances for conical seat (detail Y): ISO 2768-mH
- Discharge flanges to DIN EN 1092-1 PN6, DIN EN 1092-2 PN6

⁴⁶ Observe this dimension.

⁴⁷ Value for maximum motor length



Calculation formulas:

$$H = H_{\text{geo}} + \Delta H_v$$

$$\Delta H_v$$


- Loss in the elbow $h_{v \text{ Kr}}$ (see diagram)
- Loss in the riser (pipe friction)
- $H_{v \text{ System}}$ (valves, etc.)

$H_{v \text{ System}}$ must be determined for the specific system.

Minimum water level diagram

Open chamber

t_1 [mm]




Minimum water level

d_8 = design: **without** suction umbrella (standard)

d_9 = design: **with** suction umbrella

9.5.2.6 Installation type DG



⁴⁸ All dimensions for foundation recesses apply to discharge tube design without intermediate flange.

Table 64: Dimensions [mm]


Size	D	DN ₂ min	DN ₂ max	a	a ₁	a ₂	b	b ₁	b ₂	d ₇	d ₈	d ₁₀
650-364	660	400	600	610	810	560	1000	200	400	530	550	600
650-365	660	400	600	610	810	560	1000	200	400	530	550	600
650-404	660	400	600	610	810	560	1000	200	400	530	550	600
650-405	660	400	600	610	810	560	1250	250	500	530	660	690
800-505	813	500	800	700	960	710	1250	250	500	680	700	735

Table 65: Dimensions [mm]

Size	e ₁ ⁴⁹⁾	e ₂	h ₇	l _{min}	m	n	p ₁	p ₂	t ₃ ⁴⁹⁾	t _{4min} ⁵⁰⁾	t ₉
650-364	300	500	225	1000	860	1110	810	910	260	2350	375
650-365	300	500	225	1000	860	1110	810	910	260	2350	375
650-404	300	500	265	1000	860	1110	810	910	260	2600	375
650-405	375	625	265	1250	860	1110	810	910	320	2750	470
800-505	375	625	335	1250	1030	1260	960	1060	320	2700	470

Permissible tolerances:

- Tolerances in building construction to DIN 18202, Part 4, Group B
- Welded design: B/F to DIN EN ISO 13920
- Tolerances for conical seat (detail Y): ISO 2768-mH
- Discharge flanges to DIN EN 1092-1 PN6 / DIN EN 1092-2 PN6

Loss diagram


Calculation formulas:

$$H = H_{\text{geo}} + \Delta H_v$$

ΔH_v

- Loss in the elbow $h_{v \text{ Kr}}$ (see diagram)
- Loss in the riser (pipe friction)
- $H_{v \text{ System}}$ (valves, etc.)


$H_{v \text{ System}}$ must be determined for the specific system.

⁴⁹ Observe this dimension.

⁵⁰ Value for maximum motor length

Minimum water level diagram

Covered intake chamber



Minimum water level

9.5.2.7 Dimensions of the flow-straightening vane

Design of the intake chamber wall surfaces (to prevent vortex formation)

The flow-straightening vane is indispensable for the inlet conditions of the pump set. It prevents the development of a submerged vortex (floor vortex) which could cause a drop in performance, for example. In addition, the floor and wall surfaces of the intake chamber should be designed as a rough concrete surface. Rough surfaces minimize the separation of boundary layers that may cause wall and floor vortices.

Flow-straightening vane and intake chamber

- The anti-vortex vanes in the bellmouth must be aligned with the flow-straightening vane.
- The bail of the pump is oriented in the same direction as the anti-vortex vanes in the bellmouth.






Fig. 59: Installation position of the pump set

1	Bail
2	Anti-vortex vanes
3	Flow-straightening vane

Variant 1
Flow-straightening vane cast from concrete



Variant 2
Steel section



A	Bolted to the floor of the intake chamber
B	Flow-straightening vane centered beneath the discharge tube
C	Discharge tube
D	Intake chamber

Installation types BU, CU, DU

Table 66: Dimensions [mm]

Size	h_R	s_R	s_1	s_2	$(e_1)^{51)}$		$l_R^{52)}$	
					Suction umbrella		Suction umbrella	
					X	✓	X	✓
					d_8	d_9	d_8	d_9
650-364	150	10	20	60	420	540	835	955
650-365	150	10	20	60	420	540	835	955
650-404	150	10	20	60	420	540	835	955
650-405	190	10	20	70	420	540	875	1050
800-505	190	10	20	70	500	620	1050	1150

Installation types BG, CG, DG




Fig. 60: Flow-straightening vane for covered intake chamber

Table 67: Dimensions [mm]

Size	h_R	s_R	s_1	s_2
650-364	150	10	20	60
650-365	150	10	20	60
650-404	150	10	20	60
650-405	190	10	20	70
800-505	190	10	20	70

⁵¹ See installation examples for installation types BU, CU and DU

⁵² Adjust length l_R of the flow straightening vane to the 45° angle of the intake chamber.

10 EU Declaration of Conformity

Manufacturer:

KSB SE & Co. KGaA
Johann-Klein-Straße 9
67227 Frankenthal (Germany)

The manufacturer herewith declares that the product:

Amacan K, Amacan P, Amacan S

KSB order number:

- is in conformity with the provisions of the following directives / regulations as amended from time to time:
 - Pump (set): 2006/42/EC Machinery Directive

The manufacturer also declares that

- the following *designated standards*⁵³⁾ have been applied:
- the following harmonized international standards⁵⁴⁾ have been applied:
 - ISO 12100
 - EN 809
 - EN 60034-1, EN 60034-5/A1

Responsible for compiling the technical documentation

Name
 Function
 Address (company)
 Address (street, No.)
 Address (post or ZIP code, city) (country)

The EU Declaration of Conformity was issued in/on:

Place, Date

.....⁵⁵⁾⁵⁶⁾.....

Name
 Function
 Company
 Address

⁵³ Apart from the standards listed here referring to the *Supply of Machinery (Safety) Regulations 2008*, further standards are observed for explosion-proof versions (*Equipment and Protective Systems Intended for use in Potentially Explosive Atmospheres Regulations 2016*) as applicable and are listed in the legally binding UK Declaration of Conformity.

⁵⁴ Apart from the standards listed here referring to the Machinery Directive, further standards are observed for explosion-proof versions (ATEX Directive) as applicable and are listed in the legally binding EU Declaration of Conformity.

⁵⁵ A signed, legally binding EU Declaration of Conformity is supplied with the product.

⁵⁶ A signed, legally binding UK Declaration of Conformity is supplied with the product.

11 Certificate of Decontamination

Type:
Order number/
Order item number⁵⁷⁾:
Delivery date:
Field of application:
Fluid handled⁵⁷⁾:

Please check where applicable⁵⁷⁾:



Corrosive



Oxidizing



Flammable



Explosive



Hazardous to health



Seriously hazardous to health



Toxic



Radioactive



Hazardous to the environment



Safe

Reason for return⁵⁷⁾:
Comments:
.....

The product/accessories have been carefully drained, cleaned and decontaminated inside and outside prior to dispatch/placing at your disposal.

We herewith declare that this product is free from hazardous chemicals, biological and radioactive substances.

For mag-drive pumps, the inner rotor unit (impeller, casing cover, bearing ring carrier, plain bearing, inner rotor) has been removed from the pump and cleaned. In cases of leakage at the stator can, the stator space has been examined for fluid leakage; if fluid handled has penetrated the stator space, it has been removed.

For canned motor pumps, the rotor and plain bearing have been removed from the pump for cleaning. In cases of leakage at the stator can, the stator space has been examined for fluid leakage; if fluid handled has penetrated the stator space, it has been removed.

- ☐ No special safety precautions are required for further handling.
☐ The following safety precautions are required for flushing fluids, fluid residues and disposal:

.....
.....

We confirm that the above data and information are correct and complete and that shipping is effected in accordance with the relevant legal provisions.

.....
Place, date and signature

.....
Address

.....
Company stamp

⁵⁷⁾ Required field

Index

A

Abrasive fluids 49

B

Bearing temperature monitoring 43

Bearings 15, 20

C

Certificate of decontamination 139

Commissioning/start-up 46

D

Design 20

Designation 18

Dismantling 66

Disposal 17

Drive 20

E

Electrical connection 43

Electromagnetic compatibility 40

Event of damage 7

Ordering spare parts 82

Explosion protection 39, 41, 43, 44, 47, 48, 59

F

Faults

Causes and remedies 84

Fluid handled

Density 48

G

Grease lubrication

Grease quality 64

I

Impeller type 20

Installation 24

Intended use 9

Interference immunity 40

K

Key to safety symbols/markings 8

L

Leakage monitoring 42

Level control 39

Lubricant 59

Quantity 60

M

Maintenance 53

Mechanical seal leakage 42

O

Operating limits 9

Operation on a frequency inverter 40, 48

Order number 7

Other applicable documents 7

Overload protection 39

P

Partly completed machinery 7

Preservation 15

Product description 18

R

Reassembly 66, 72

Return to supplier 16

Returning to service 50

S

Safety 9

Safety awareness 10

Scope of supply 23

Sensors 41

Shaft seal 20

Shutdown 50

Spare part

Ordering spare parts 82

Spare parts stock 83

Start-up 47

Storage 50

Supply voltage 47

T

Tightening torque 81

Tightening torques 82

W

Warnings 8

Warranty claims 7



KSB SE & Co. KGaA

Johann-Klein-Straße 9 • 67227 Frankenthal (Germany)

Tel. +49 6233 86-0

www.ksb.com

1589.826/02-EN-US